

BT-200
User Guide

Includes:

BT-200, charge cable, 2 removable ear clips, 2 sets of silicone tips (S/L), removable cable management clip, and user guide

Please read and follow this user guide thoroughly before using the BT-200.

1. Microphone	4. Power/Phone
2. Volume Down/Track Back	5. Volume Up/Track Forward
3. Charge Port	6. LED Power Indicator

Specifications

Frequency response: 20 Hz – 20 kHz

Driver size: 10mm

Impedance: 16 omega

Sensitivity: 110±5dB

Bluetooth v4.1 + EDR, up to a 30 foot transmission range

Battery capacity: 70mAh

Play time: Up to 2.0 hours based on usage

Charge time: 2 hours

Button functions

Power/phone button

- Press and hold for at least 5 seconds to power on the BT-200; press and hold for at least 5 seconds to power off the BT-200.
- When playing music, press and release to pause music; press and release again to play music.
- When receiving an incoming call, press and release to answer; press and release again to end the call; press and hold for 3 seconds then release to reject the call.
- Press twice quickly to call last number dialed.
- When a user is connected and the BT-200 is off, press and hold for at least 5 seconds to unpair from Bluetooth (allow another user to connect).

NOTES:

- During the first time set-up, you must hold the power/phone button down until you hear a voice say "Power on", then followed by "Ready for pairing" in order to sync your device to Bluetooth. After the initial pairing, you can let go of the power/phone button after you hear a voice say "Power on".
- When playing music and a call comes in, the music will pause and you will hear a ringtone. The music will resume when the call is ended. Device's ringtone may vary.??
- If you reject a phone call, you will hear a voice say "Phone call rejected" and your music will resume playing. If the music does not begin, press and release the power/phone button again to resume the current track.
- The power/phone button functions may vary per device.

Volume up/track forward button

- Press and release to raise the volume.
- Press and hold to go to the next track.

NOTE: The volume up/down buttons may control the volume on your device. Device's results may vary.

Volume down/track back button

- Press and release to lower the volume.
- Press and hold to go to the previous song.

NOTE: The volume up/down buttons may control the volume on your device. Device's results may vary.

Charging your BT-200

NOTE: Make sure your BT-200 is fully charged before using it the first time.

1. Gently plug the Micro-USB end of the included charge cable into the charge port of the control box.
2. Plug the USB A end of the cable into a powered USB port, such as a computer, laptop, or USB AC adapter (not included).
3. The LED power indicator located next to the volume up/track forward button will light up solid red. Once the headset is fully charged, the LED power indicator will turn off.

NOTES:

- When the battery level is below 10%, you will hear a voice say "Battery level low". Charge your BT-200 with the included charge cable. This feature only works while the BT-200 is on.
- The LED power indicator will light up red while charging even if the BT-200 is off.
- You can charge your BT-200 while listening to music, however, this extends the charging time.

Connecting via Bluetooth® (first time set-up)

1. Press and hold the power/phone button for at least 5 seconds to turn the headset on.

You will hear a voice say "Power on", then continue to hold the button until you hear "Ready for pairing" and the LED power indicator will rapidly flash blue and red.

NOTE: During the first time set-up, you must hold the power/phone button down until you hear a voice say "Power on" then followed by "Ready for pairing" in order to sync your device to Bluetooth. After the initial pairing, you can let go of the power/phone button after you hear "Power on".

2. Open the settings on your Bluetooth device. (Bluetooth must be enabled)
3. Select "BT-200" from the list of Bluetooth devices.
4. Once paired, you will hear a voice say "Device connected". The LED power indicator light will flash blue slowly.
5. To turn off the BT-200, press and hold the power/- phone button for at least 5 seconds. You will hear a voice say "Power off" before the headset turns off.


NOTES:

- Upon use of your BT-200 the volume must be adjusted to your desired level, as the volume level has been pre-set to the maximum. (30% initial volume setting)
- Your device will automatically find and pair with the BT-200 after the initial pairing. If your device does not automatically pair within 5 minutes, the BT-200 switches off. You can switch on the headset and repeat steps 1-4.
- The BT-200 will automatically pair to the last device connected.
- The volume up/down buttons on the BT-200 may control the volume on your device.

Device's results may vary.

Cable management

To loosen the removable cable management clip.



Troubleshooting

Issue: My BT-200 doesn't turn on.

Solution: Try the following:

- Make sure the BT-200 is charged.
- Make sure the volume is turned up on your device and the BT-200.
- Make sure you press and hold the power/phone button for at least 5 seconds.

Issue: My BT-200 is not charging.

Solution: Try the following:

- Make sure the charge cable is fully inserted in the BT-200.
- Make sure that the charge port on the headset is free from dust and debris.
- Make sure that you are using the charge cable that came with your BT-200.
- Make sure there is power coming from the power source.

Issue: My BT-200 isn't syncing to Bluetooth.

Solution: Try the following:

- Make sure you hold the power/phone button down until you hear a voice say "Ready for pairing" after it says "Power on".
- Make sure that the Bluetooth setting is turned "on" on your device.
- Check to see if another user is connected to the BT-200.
- Refer to the user guide of your device for Bluetooth syncing instructions.

Issue: My BT-200 volume is turned all the way up, but the volume is still very low.

Solution: Try the following:

- Make sure your BT-200 and audio device are charged.
- Make sure the volume is turned up on your device and the BT-200.

Issue: The person on the other line cannot hear me very well.

Solution: Try the following:

- Make sure your BT-200 and phone are charged.
- Make sure there is nothing covering the microphone on the control box.
- Make sure you have service with your phone provider.

Safety warning

- Do not listen at a high volume level. Extended high volume levels can lead to permanent hearing loss.
- Start with setting the volume level at the lowest volume and adjust until you reach a comfortable volume level.
- Tampering or removing the battery can result in damage to your product, void of warranty, and could cause injuries.
- Do not use when a failure to hear your surroundings could be dangerous, such as while driving, or when biking, walking or jogging where traffic is present and accidents may occur.
- Do not use while sleeping, as accidents may occur.
- If you experience any ringing in your ears, try lowering the volume. If the ringing persists, visit your physician.

Important safety precautions

- Incorrect use or incompatibility with your device may result in reduced battery performance or damage to your device.
- Do not attempt to disassemble product.
- Tampering or removing the battery can result in damage to your product, void of warranty, and could cause injuries.
- Do not allow this product to have contact with liquids.
- Store and operate between 32°F – 113°F.
- Do not place this product near a heat source or flame.
- Do not throw or shake.
- Do not operate if it has been subjected to shock or damage.
- Do not crush or puncture the battery.
- Recharge the battery every 3 months when not in use to keep battery in best condition.

- Use soft cloth to clean the exterior. Do not use harsh chemicals or strong cleaning solvents.
- The internal battery must be recycled or disposed of properly. Contact your local waste management office for information on the proper disposal or recycling.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Save a tree, register online

i.Sound is making the eco-friendly choice to have all products registered online. This saves the printing of physical paper registration cards. All the information you need to register your recent i.Sound purchase is available at: www.isound.com/product-registration