



















CAUTION
DO NOT OPEN THE DRIVE WITH A POWER SUPPLY
CONNECTED. ALWAYS DISCONNECT THE POWER
SUPPLY BEFORE OPENING THE DRIVE.

A2F3P4H650

502104
P3

SONY

PAB

