







MOREY

Omnilink OM400









BATTERY
WIRE HARNESS

PUSH BUTTON
SWITCH

SWITCH
WIRE HARNESS

