

SAR Test Setup




Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 2: Back Side2, the distance from EUT to the bottom of the Phantom is 0mm



Picture 3: Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 4: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 5: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 6: Bottom Edge, the distance from EUT to the bottom of the Phantom is 0mm