



FRONT CASE FRONT SIDE



Remove FRONT CASE BACK SIDE



KNOB




Remove HEATSINK




COVER




FRONT BACK SIDE



Remove FRONT PANEL




FRONT PANEL BACK SIDE




MAIN PCB TOP



TOP OPEN



BOTTOM OPEN



BOTTOM PCB

