

SHARP Carousel



MINUTE PLUS

INSTANT ACTION

TO SELECT SHORTCUT, PRESS THE ICON




1. Popcorn
2. Reheat
3. Defrost
4. Hot Water
5. Hard-Boiled Eggs
6. Smoothies
7. Steam Rice
8. Microwave
9. Power Freeze

1 2 3
4 5 6
7 8 9

POWER LEVEL 0 TIMER CLOCK

STOP CLEAR START





MINUTE PLUS

INSTANT ACTION

TO ADJUST QUANTITY - TOUCH PAD AGAIN



DRINKER PLATE



RICE



POPCORN



FROZEN
ROLL/MUFFIN



BAKED POTATOES



FRESH VEG.



FROZEN
ROLL/MUFFIN



FROZEN
VEGETABLES



FROZEN
MAIN DISH

1. Ground Meat
2. Steaks/Chops
3. Chicken Pieces

COMPU
DEFROST

1

2

3

4

5

6

7

8

9


POWER
LEVEL


0


TIMER
CLOCK


STOP
CLEAR


START
























VR UL #1

