

## Music Playback

### Using Music&Video Channel

The Music&Video Channel service is provided in Japanese.

- 1 In the Normal menu, [CAMERA/TV/MUSIC] ▶ [Music&Video Channel]
- 2 Select a program

### Using MUSIC Player

- 1 In the Normal menu, [Data box] ▶ [MUSIC]
- 2 Select music data

## Network Services

### Setting Voice Mail Service

Voice Mail Service is a paid option (monthly fees apply) that requires subscription.

- 1 In the Normal menu, [TEL function] ▶ [Voice mail service]
- 2 [Activate] ▶ [Yes] ▶ [Yes] ▶ enter the ringing time ▶ [OK]

### Setting Call waiting service

Call waiting service is a paid option (monthly fees apply) that requires subscription.

- 1 In the Normal menu, [TEL function] ▶ [Other network service] ▶ [Call waiting]
- 2 [Activate] ▶ [Yes] ▶ [OK]

### Setting Call Forwarding Service

Call Forwarding Service is a free option (no monthly fees) that requires subscription.

- 1 In the Normal menu, [TEL function] ▶ [Other network service] ▶ [Call forwarding]
- 2 [Activate] ▶ [Yes] ▶ [Yes] ▶ enter a phone number ▶ [Complete] ▶ [Yes] ▶ enter the ringing time ▶ [OK]

## Osaifu-Keitai

Hold the  mark of the FOMA terminal over the scanning device to use as electronic money or railway tickets or to retrieve ToruCa.

- When the FOMA terminal is stolen or lost, immediately contact your provider of Osaifu-Keitai compatible service for handling methods.

## Bluetooth function

- The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by NTT DOCOMO, INC. is under license. Other trademarks and trade names are those of their respective owners.

### Registering Bluetooth devices on FOMA terminal

- Switch the other party's Bluetooth device to the registration stand-by status in advance.
- 1 In the Normal menu, [Tool] ▶ [Bluetooth] ▶ [List/cnnect/discnct]
    - The device list screen appears when registered device exists. Select [Search] and proceed to step 3.
  - 2 [Yes]
  - 3 Point the cursor to the Bluetooth device to register ▶ [Submenu] ▶ [Register Devices]
  - 4 Enter the Bluetooth passkey

### Connecting with Bluetooth devices

- 1 In the Normal menu, [Tool] ▶ [Bluetooth] ▶ [List/cnnect/discnct]
- 2 Select a Bluetooth device to connect to

## General Notes

### Introduction of options and related devices

- Battery Pack SH26
- FOMA AC Adapter 01 for Global use
- FOMA AC Adapter 01/02

## Main specifications

Size	\$\$ (H) × \$\$ (W) × \$\$ (D) mm (\$\$ at thickest point)	
Weight	\$\$ g (with battery pack attached)*	
Continuous talk time	FOMA/3G	Voice call: \$\$ min* Videophone: \$\$ min*
Continuous stand-by time	FOMA/3G	When mobile: \$\$ hr* At rest: \$\$ hr*
Charge time	FOMA AC Adapter 01/02	\$\$ min*
	FOMA DC Adapter 01/02	\$\$ min*

\* Approximate value