

Bluetooth speaker
IBOMB Thunder Ball EX800
USER GUIDE
FCC ID:AXE-EX800

IBomb®
Enjoy music ,Enjoy life

Set your IBOMB Thunder Ball wireless Bluetooth™

Your Eyes Won't Believe Your Ears
Huge Sound!

2 PAIR DEVICE

10m RANGE

Turn on Bluetooth on your device and search the "IBOMB EX800", Select it to connect.

1 PAIRING MODE

Switch to the "ON" Posting ,LED Light indicator light will flash blue indicating that the Ibomb Thunder Ball is in pairing mode.

The IBOMB Thunder Ball will "beep"; indicating that it has successfully paired with you device

TURN ON/OFF

ON/OFF switch is located at the bottom of the device.

3 PLAY

If you are prompted to enter a password to complete pairing,enter"0000"

If a device is not connected after 30 seconds; it will enter sleep mode automatically.
Turn the speaker OFF and then ON again to re-enter pairing mode.

i If the IBOMB Thunder Ball is moved out of rang start again to re-enter the connection.

Change function mode

IBomb

Shor press of "M" Button is switching mode between TF card ,AUX and Bluetooth.

wired

Playing music with a 3.5mm Cable
Plug the provided 3.5mm audio cable into the IBOMB Thunder Ball and then connect your source.

How to use?




SHORT PRESS **LONG PRESS**

Play / Pause

Next song Volume up

Previous song Volume down

Change play music mode (Bluetooth/TF card/Wired)



When your call coming, please plus PLAY/ PAUSE button to pick up your phone .



Embedded microphone for handsfree conversation.



Fail to pair

Make sure the device is in pairing mode and the blue light is flashing.
Please reset (on/off)the power switch again.

TROUBLESHOOTING

Fail to find IBomb EX800

Check that the speaker is in pairing mode.
Ensure your device is within Wireless use range.
Reset your device to activate Wireless.
Ensure that your device is not connected /paired to any other Wireless devices as Wireless can only be paired to one device at a time.



Charging FIRST TIME

Make sure the device is turned OFF.
Plug the speaker to a powered USB port.
While charging the Indicator LED light will be red.
Once fully charged ,the red LED light will turn OFF.



To avoid damage to your battery only charge them when flat.



Device only works with
Micro SD cards up to 32GB.



**Play your music
anywhere you go;**
directly from the device
using the micro sd slot.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

what's in the box?

IBomb

- 1 IBOMB Thunder Ball
- 1 Audio cable
- 1 USB cable
- 1 User manual

Web: WWW.I-BOMB.COM

More question please mail to :Info@I-BOMB.COM