


Label and Label Placement

< Label Description >



< Label Placement >

The label is stuck to a shielding cover on the module.

