

HP iPAQ Voice Messenger
Product Guide



© Copyright 2008 Hewlett-Packard
Development Company, L.P.

HP iPAQ products are powered by
Microsoft® Windows Mobile® 6.1 with
Messaging and Security Feature Pack.

Microsoft Windows, the Windows logo,
Outlook, Windows Mobile Device Center,
and ActiveSync are trademarks of
Microsoft Corporation in the U.S. and other
countries.



Java and all Java-based trademarks and
logos are trademarks or registered
trademarks of Sun Microsystems, Inc. in the
U.S. and other countries.



SD Logo is a trademark of its proprietor.

Bluetooth® is a trademark owned by its
proprietor and used by Hewlett-Packard
Development Company, L.P. under license.

Google and Google Maps™ are trademarks
of Google Inc.

All other product names mentioned herein
may be trademarks of their respective
companies.

Hewlett-Packard Company shall not be liable
for technical or editorial errors or omissions
contained herein. The information is
provided 'as is' without warranty of any kind
and is subject to change without notice. The
warranties for Hewlett-Packard products are
set forth in the express limited warranty
statements accompanying such products.
Nothing herein should be construed as an
additional warranty.

This document contains proprietary
information that is protected by copyright. No
part of this document may be photocopied,
reproduced, or translated to another
language without the prior written consent of
Hewlett-Packard Development Company,
L.P.

First Edition November 2008

Document Part Number: 496988-001.

Table of contents

1 Welcome to your HP iPAQ and product registration

2 Box contents

3 Components

Front panel components	3
Top panel components	4
Left and Right panel components	5
Back panel components	5

4 Set up your HP iPAQ

Step 1: Remove the battery cover and insert the SIM card	7
Step 2: Insert the battery and replace the battery cover	8
Step 3: Charge the battery	9
Step 4: Turn on your HP iPAQ	9

5 Get started with your HP iPAQ

Home screen	11
Getting Started	12
Status icons	12
Keyboard	13
Answer/Send key	13
End key	13
Home key	13
Back key	13
Softkeys	13
Keyboard layout	13
Enter text	14
Enter key	15
Backspace key	15
Shift key	16
Options key	16
Symbol key	16
Center button	16
Know your HP iPAQ	17
Find information about your HP iPAQ	17
Access programs	17

View the operating system (OS) information	17
Check the connection and signal strength	18
Customize your HP iPAQ	18
Create a device name	18
Enter owner information	18
Change the regional settings	19
Adjust the volume settings	19
Adjust the ring tone and notification sounds	19
Manage profiles	19
Use profiles	19
Edit profiles	20
Change the power management settings	20
Adjust the brightness settings	20
Increase the font size	21
Install and remove programs	21
Set clocks and alarms	22
Use Key Guard	22
Lock and unlock your HP iPAQ	23
Use the SIM PIN to protect information on your HP iPAQ	24
Battery saving tips	24
HP Power Save Mode	25

6 Use your HP iPAQ

Call features	26
Make calls	26
Make calls from the Home screen	26
Make calls from Contacts	26
Redial a number	26
Answer calls	26
Mute a call	27
Put a call on hold	27
Create an appointment during a call	27
Use call waiting	27
Make emergency calls	28
Make calls using speed dial	28
Make data calls	28
Make a conference call	29
Make a call from a hyperlinked phone number	29
Make international calls	29
Use voice mail	29
Use the handsfree function	30
Call history	30
Manage calls using call history	30

Make calls using call history	30
View the call details	30
Voice commands	31
Change the service settings	31
Auto Answer	31
Band Control	31
Call Options	32
Forward calls	32
Call waiting	33
Caller ID	33
Block calls	33
Configure channels	34
Fixed Dialing	34
Change the network settings	35
View the available phone networks	35
Set the preferred networks	35
Manually select a phone network	36
Select a frequency band	36
Voice notes	36
Create a voice note	36
Listen to voice notes	36
Rename voice notes	37
Reply to e-mails using voice notes	37
Delete voice notes	37
Reset your HP iPAQ	37
Perform a soft reset	37
Perform a hard reset (factory reset)	37

7 Storage cards

Insert a storage card	39
Remove a storage card	40
View contents of a storage card	41

8 Contacts

Create a contact	42
Edit the contact information	42
Copy a contact	42
Create and assign a category for a contact	43
Find a contact	43
Send an e-mail message to a contact	43
Send a text message to a contact	43
Add or remove a picture	44
Delete a contact	44

Use the contact list	44
9 Messaging	
Understand messages	46
Text messaging	46
MMS and its uses	47
Set up e-mail accounts	48
Set up e-mail using Exchange Server	48
Internet e-mail	48
Create a new POP3 or IMAP4 account	48
Change the e-mail download options	50
Delete an account	50
Synchronize e-mail	51
Use messaging	51
Folder types	51
Compose and send e-mails	52
Reply to or forward a message	52
Add an attachment to a message	53
Receive attachments	53
Receive meeting requests	53
Create or change a signature	54
Download messages	54
Download messages from a server	55
Install an online address book	55
10 Calendar	
Create a new appointment	57
Assign a sensitivity level to an appointment	57
Change the display of the work week	57
Set a default reminder for all new appointments	58
Update an appointment	58
Cancel an appointment	58
11 Tasks	
Create a new task	59
Create and assign a category to a task	59
Set the start and due dates for a task	59
Show the start and due dates in the task list	59
Mark a task as completed	60
12 Camera	
Use the camera	61
Capture photos	61

View photos	61
Camera settings	61
Basic settings	61
Photo settings	62
Use the video recorder	65
Record videos	65
Video settings	65
Transfer images	66
Use GPRS	66
Use Bluetooth	66

13 Connections

Use Wireless Manager	67
HSPA/GPRS/EDGE	67
HSPA	67
GPRS/EDGE	68
Differences between GSM and GPRS/EDGE/WCDMA/3G technology	68
Configure GPRS network settings	68
Edit an Internet connection	68
Edit WAP information settings	69
Troubleshoot automatic detection	70
Bluetooth	70
Bluetooth terms	70
Open Bluetooth settings	71
Connect to a computer using Bluetooth	71
Create, end, and accept a Bluetooth partnership	72
Edit a Bluetooth partnership	73
Bluetooth device profiles	73
Set up an incoming or outgoing Bluetooth communications (COM) port	74
End a Bluetooth connection	74
Wi-Fi	74
Wi-Fi terms	75
Open Wi-Fi settings	76
Automatically connect to a Wi-Fi network	76
Manually connect to a Wi-Fi network	76
Delete a Wi-Fi network	77
End a Wi-Fi connection	77
Configuring 802.1x authentication settings	77
Advanced settings	77
Connect to intranet URLs	78
Change an intranet URL	78
Set up a WAP gateway	78
Configure advanced proxy settings	78

Advanced connection settings	79
Set up a VPN server connection	79
End a connection	80

14 Synchronization

Synchronization software	81
Set up the Synchronization application	81
Synchronize data and copy files	82
Port data to Microsoft Windows Mobile 6.1	83
Troubleshoot synchronization issues	83
Customized links in WMDC	85

15 Applications

ArcSoft Streaming Player	86
Global Positioning System (GPS)	86
Use GPS	86
Use GPS Connection Utility	87
Google Maps™ for mobile	87
Google Search	88
Launch Google Search	88
HP Help and Support	88
HP Asset Viewer	88
Getting Started	89
Customer Support	89
HP Enterprise Mobility Suite	89
HP iPAQ DataConnect	89
HP iPAQ Key Guard	90
Internet Explorer®	90
Internet Sharing	90
To connect to a computer using a USB data connection	90
To connect to a computer using Bluetooth data connection	91
Java Virtual Machine	91
Jetcet PDF	92
Jetcet Print	92
MSN Messenger	93
Office Mobile applications	93
Word® Mobile	93
Excel® Mobile	93
PowerPoint® Mobile	94
OneNote® Mobile	95
Pictures & Videos	95
View the pictures stored on your HP iPAQ or on a storage card	95
View a slideshow	96

E-mail pictures	96
Associate a contact with a picture	97
Assign a picture to the Home screen background	97
HP Snapfish Upload	97
HP Enhance Document	97
Switch to the camera	98
Video support	98
Remote Desktop Mobile	98
SIM Manager	99
Manage certificates	99
Task Manager	100
Voice Commander	100
Windows Live™	101
Windows Media® Player	103
Clear the Now Playing List	103
Update the Library	104
Use Voice Commander to play media files	104
Windows Update	104

16 Product specifications

System specifications	105
Physical specifications	105
Operating environment	106

17 Guidelines for care and maintenance

Use your HP iPAQ	107
Clean your HP iPAQ	107
Carry or store your HP iPAQ	107
Use accessories	107

18 Frequently asked questions

Battery	108
Connection	110
Synchronization	112
Miscellaneous	112

19 Optional accessories

20 Safety information

General precautions	114
Safety precautions for power cords and accessories	115
Safety precautions for battery packs	115

Safety precautions for docking devices	116
Safety precautions for products with wireless devices	116
Safety precautions for products with modems, telecommunications or local area network accessories	116

21 Regulatory notices

Federal Communications Commission Notice	117
Modifications	117
Cables	117
Declaration of Conformity for Products Marked with the FCC Logo (United States Only)	118
Canadian Notice	118
Avis Canadien	118
European Union Notice	118
Products with 2.4-GHz Wireless LAN Devices	120
France	120
Battery Warning	120
Battery Recycling	120
Battery Disposal	120
Chemical substances	120
Disposal of Waste Equipment by Users in Private Household	121
Equipment Warning	125
Acoustics Warning	125
Airline Travel Notice	126
Medical Electronic Equipment	126
SAR Notice	126
Wireless Notices	127
U.S. Regulatory Wireless Notice	127
Canadian Regulatory Wireless Notice	127
Brazilian Notice	127
Singaporean Wireless Notice	127
Thailand Wireless Notice	128
Wireless LAN 802.11b Devices	128
Wireless LAN 802.11g Devices	128
Bluetooth Devices	128

22 Quick reference

Acronyms	129
Icons used	131

Index	132
--------------------	------------

1 Welcome to your HP iPAQ and product registration

Welcome and congratulations on the purchase of your HP iPAQ Voice Messenger!

This Product Guide provides you with instructions necessary to set up, use and enjoy your new HP iPAQ. Please read the user instructions contained in this Product Guide before using your HP iPAQ. This Product Guide will give you a comprehensive understanding of all the features and functionalities available in your HP iPAQ Voice Messenger and enables you to use them to its fullest potential.

 **NOTE:** In addition to the instructions contained in this HP iPAQ Product Guide, you can find further product information at <http://www.hp.com/support>.

We also invite you to register your new HP iPAQ with Hewlett-Packard to perform the following tasks:


- Access support and services, and get the most out of your HP products.
- Sign up for free support alerts, software updates, and personalized newsletters.

Visit <http://www.register.hp.com> to register your HP iPAQ or to update your postal or e-mail address after registration. You are required to enter your user ID and registration password to edit your online profile. After registering your HP iPAQ, you will receive an e-mail message on special offers and promotions.

 **NOTE:** Registration is not supported in all countries/regions.

2 Box contents

This illustration shows the items that are included in the box with your HP iPAQ.




(1)	HP iPAQ Voice Messenger
(2)	Getting Started CD with additional software
(3)	1260 mAh Li-polymer removable/rechargeable battery
(4)	Welcome Guide
(5)	Getting Started Guide
(6)	AC adapter NOTE: The AC adapter shipped with your HP iPAQ might vary depending on the country/region.
(7)	Micro-USB synchronization cable
(8)	2.5 mm wired stereo headset

3 Components

Identify the different components of your HP iPAQ, understand its functions, and use your HP iPAQ to its full potential.


Front panel components



Component	Description	Function
(1)	Receiver	Use to listen to phone calls, sounds, and notifications.
(2)	Display	Use to view the on-screen contents.
(3)	Right Softkey	Press to access the displayed functions and menus.
(4)	End/Power Key	Performs the following functions: <ul style="list-style-type: none"> • Press and hold to turn your HP iPAQ on and off. • Press to end a phone call. • Press to return to the Home screen from any program. • Press to activate the device from sleep mode.
(5)	Back Key	Press to return to the previous screen or exit a program. Press to activate the device from sleep mode.
(6)	QWERTY Keyboard	Use keys on the keyboard to enter text or dial numbers. Press to activate the device from sleep mode. NOTE: The keyboard layout on your HP iPAQ might vary depending on the country/region.
(7)	5-way Optical Navigation with Center Select Button	Navigate up, down, left, and right on the screen. Slide your thumb or finger in the direction you want to scroll. Press the Center button to select the item highlighted on the screen.


Component	Description	Function
(8)	Microphone	Use the microphone for making phone conversations, recording notes, and providing voice commands to your HP iPAQ.
(9)	Home Key	Press to return to the Home screen from any program. NOTE: Press and hold to view the Quick List .
(10)	Answer/Send Key	Performs the following functions: <ul style="list-style-type: none"> • Press to answer a call. • Press to make a call from Call or Contacts list. • Press twice to redial the last dialed number. • Press to activate the device from sleep mode.
(11)	Left Softkey	Press to display the Start menu from the Home screen to access programs and perform the function displayed on the screen.
(12)	LEDs	Indicates battery, network, or device status. <ul style="list-style-type: none"> • Quick 3 Blink Red - Device or charging error • Blinking Orange - Phone on and out of coverage area, or phone on with no SIM card present • Solid Green - Battery fully charged and connected to the power source • Solid Red - Charging when the battery is low • Blinking Red - Low battery warning

Top panel components




Component	Description	Function
(1)	Back Cover Latch	Press to release the back cover.
(2)	Ringer/Sound Switch	Use to switch off incoming call rings and system notification alert sounds.

Left and Right panel components



Component	Description	Function
(1)	Key Guard Button	Press to lock the keyboard. Press to activate the device from sleep mode.
(2)	Volume Up/Down Key	Press to increase or decrease the volume. Press once to temporarily mute the ringtone and notification sounds.
(3)	Voice Commander Button	Press and hold to launch Voice Commander .
(4)	Stereo Headphone Jack (2.5mm)	Use to connect the stereo headphones to your HP iPAQ.
(5)	Micro-USB Connector	Use to connect the Micro-USB synchronization cable and the charger.
(6)	Camera Button	Use to launch the camera to capture photos and videos.

Back panel components



Component	Description	Function
(1)	3.1 Mega Pixel Camera	Auto-focus 5x digital zoom camera, use to capture photos and videos.
(2)	Speaker	Use the speaker to listen to music or as a speakerphone.
(3)	Camera Flash LED	Use the camera flash LED to illuminate your subject while you capture photos.
(4)	Back Cover	Remove to insert or remove the battery, the SIM card, and the microSD card.


4 Set up your HP iPAQ

Follow these steps to set up and use your HP iPAQ. Carefully remove your HP iPAQ and all the components from the box before beginning to set up your HP iPAQ.


 **NOTE:** Do not place your HP iPAQ on a hard surface with the screen facing down. Placing the screen on hard surface can cause scratches on the screen surface.

Step 1: Remove the battery cover and insert the SIM card

1. Press the back cover release latch (1), and then pull the back cover (2) from your HP iPAQ as shown in the figure.



2. Slide the SIM card into the SIM card slot.




 **NOTE:** If the battery is already inserted, remove it before inserting the SIM card. Also, make sure that the metal contacts are facing down and the notched corner is in the correct position. If the SIM card is not properly inserted in the HP iPAQ,  (No SIM card installed icon) will be displayed on the title bar at the top-right corner of the screen after you turn on your HP iPAQ.

The SIM card is provided by a mobile phone service provider.

If your HP iPAQ is SIM-locked, please contact your service provider.

Step 2: Insert the battery and replace the battery cover

1. Align the battery connectors on the battery with the housing pins in the battery compartment and insert the battery.



2. Replace the battery cover and press at the top and bottom of the cover until it locks into place.



Step 3: Charge the battery



△ **CAUTION:** To avoid damaging your HP iPAQ or the AC adapter, make sure all the metal connectors are correctly aligned before connecting to the power source.

The battery provides power for your HP iPAQ to operate. Use the AC adapter to charge the battery inside your HP iPAQ.

It takes approximately 2 to 4 hours to fully charge the battery for the first time. Charging might take more time when your HP iPAQ is connected to a powered computer or with non-HP accessories.

To charge the battery:

1. Connect the AC adapter (input: 100-240VAC, 47-63Hz, output: 5VDC, 1A) to an electrical outlet.
2. Connect the other end of the cable to the Micro-USB connector port on your HP iPAQ. The cable connector only fits one way. If the connector does not insert easily, turn it over.

💡 **TIP:** You can also charge the battery by connecting your HP iPAQ to a USB port on your computer through the Micro-USB synchronization cable. The HP iPAQ must be turned on for it to be charged using the USB connection. The LED indicator turns solid red while the battery is charging.

Step 4: Turn on your HP iPAQ

Press and hold the **Power** key for a few seconds to turn on your HP iPAQ. Follow the instructions on the screen to complete the setup. Use the keyboard to enter information. For more information, see [Keyboard on page 13](#).

 **NOTE:** The first time you turn on your HP iPAQ, it will take a few minutes to become fully functional. The keyboard will not be active during this period.
