


7. SETUP PHOTOS

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP



DFS BACK PHOTO (EUT)



DFS FULL SETUP PHOTO (CLIENT MODE SETUP)



DFS FULL SETUP PHOTO (CLIENT-TO-CLIENT
COMMUNICATIONS MODE SETUP)



END OF REPORT