







HIGH CHANNEL 11 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 11




HIGH CHANNEL 12 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 12




HIGH CHANNEL 13 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 13


1TX Antenna 3 MODE




LOW CHANNEL 1 BANDEDGE




OUT-OF-BAND LOW CHANNEL 1




LOW CHANNEL 2 BANDEDGE




OUT-OF-BAND LOW CHANNEL 2




LOW CHANNEL 3 BANDEDGE




OUT-OF-BAND LOW CHANNEL 3







HIGH CHANNEL 11 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 11




HIGH CHANNEL 12 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 12




HIGH CHANNEL 13 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 13


2TX Antenna 4 + Antenna 3 CDD MODE




LOW CHANNEL 1 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 1 ANT 4




LOW CHANNEL 2 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 2 ANT 4




LOW CHANNEL 3 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 3 ANT 4




IN-BAND REFERENCE LEVEL ANT 4




OUT-OF-BAND MID CHANNEL ANT 4




HIGH CHANNEL 9 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 9 ANT 4




HIGH CHANNEL 10 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 10 ANT 4




HIGH CHANNEL 11 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 11 ANT 4




HIGH CHANNEL 12 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 12 ANT 4




HIGH CHANNEL 13 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 13 ANT 4




LOW CHANNEL 1 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 1 ANT 3




LOW CHANNEL 2 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 2 ANT 3




LOW CHANNEL 3 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 3 ANT 3




IN-BAND REFERENCE LEVEL ANT 3




OUT-OF-BAND MID CHANNEL ANT 3




HIGH CHANNEL 9 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 9 ANT 3




HIGH CHANNEL 10 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 10 ANT 3




HIGH CHANNEL 11 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 11 ANT 3




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3



HIGH CHANNEL 13 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 13 ANT 3