

A3089, A3090, A3092

Touch Screen Assembly, Earpiece, Microphone - Back



A3089, A3090, A3092

Back Plate



A3089, A3090, A3092

Battery - Front



A3089, A3090, A3092

Battery - Back



A3089, A3090, A3092

ANT4, ANT 10 - Front



A3089, A3090, A3092

ANT4, ANT 10 - Back




A3089, A3090, A3092

Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Front



A3089, A3090, A3092

Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Back




A3089, A3090, A3092

Rear Camera - Front




A3089, A3090, A3092

Rear Camera - Back




A3089, A3090, A3092

Top Speaker and Flex Assembly
with ANT2, ANT8, ANT6/
SharedUWB0, UWB1 - Front




A3089, A3090, A3092

Top Speaker and Flex Assembly
with ANT2, ANT8, ANT6/
SharedUWB0, UWB1 - Back




A3089, A3090, A3092

Flex Assembly with USB-C
Connector, Microphone , ANT1,
Ant7, Ant3, ANT9, ANT5 - Front





A3089, A3090, A3092

Flex Assembly with USB-C
Connector, Microphone , ANT1,
Ant7, Ant3, ANT9, ANT5 - Back




A3089, A3090, A3092
Bottom Speaker - Front






A3089, A3090, A3092

MLB - Front





A3089, A3090, A3092


MLB - Back



A3089, A3090, A3092
MLB without Shields - Front








WiFi/BT Radio Chipset

Cellular Radio Chipset

A3089, A3090, A3092

UICC SIM Tray - Front



A3089, A3090, A3092

UICC SIM Tray - Back

