




Note: MSS not supported by A3297

A3295, A3296, A3297

Back Plate






A3295, A3296, A3297


Battery - Back



A3295, A3296, A3297
ANT4 Front




A3295, A3296, A3297
ANT4 Back




A3295, A3296, A3297


Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Front



A3295, A3296, A3297

Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Back








A3295, A3296, A3297

Top Speaker and Flex Assembly
with ANT2, ANT8/UWB1, ANT10,
ANT6/SharedUWB0 - Front



A3295, A3296, A3297

Top Speaker and Flex Assembly
with ANT2, ANT8/UWB1, ANT10,
ANT6/SharedUWBO - Back

