


A3260, A3516, A3517, A3518 - Front

Multi-Touch Panel, Display, Earpiece Receiver
Face-time Camera



A3260, A3516, A3517, A3518 - Back
Rear Camera, Microphone, Flash Light




A3260, A3516, A3517, A3518 -Right

Sleep/Wake Button and a
Camera Control Button



A3260, A3516, A3517, A3518 - Left
Ring/Silent Button and Volume Buttons



A3260, A3516, A3517, A3518 - Bottom
Speakers, USB-C Connector, Microphone



