


A2324, A2072, A2325

Multi-Touch display panel removed




A2324, A2072, A2325

Display panel - Back




A2324, A2072, A2325

Antenna 4 - Front



A2324, A2072, A2325

Antenna 4 - Back



A2324, A2072, A2325

Antenna 3B and Antenna 3A - Front




A2324, A2072, A2325

Antenna 3B and Antenna 3A - Back




A2324, A2072, A2325

Antenna 1A, Antenna 1B,
Antenna 2B, Antenna 2A - Front



A2324, A2072, A2325

Antenna 1A,
Antenna 1B,
Antenna 2B,
Antenna 2A - Back



A2324, A2072, A2325

USB-C connector assembly - Front




A2324, A2072, A2325

USB-C connector assembly - Back




A2324, A2072, A2325

Front and
Back Cameras - Front



A2324, A2072, A2325


Front and
Back Cameras - Back



A2324, A2072, A2325

Top and Bottom


Left Speaker - Front



A2324, A2072, A2325

Top and Bottom

Left Speaker - Back




A2324, A2072, A2325

Battery - Front




A2324, A2072, A2325

MLB with Shield - Front



A2324, A2072, A2325

MLB - Back



A2324, A2072, A2325

MLB with shield removed - Front

