

A2436

Multi-Touch Display Panel Removed

Antenna WF7

Top Left
Speaker

Battery

Bottom Left
Speaker

Front Camera

Antenna WF8

Top Right Speaker

Rear Camera

Antenna WF5T


Battery

MLB with Cover


Antenna WF5B

Bottom Right Speaker

USB-C Port Assembly



A2436
Display Panel - Back



A2436

Antenna WF7, Antenna WF8 - Front

