




A2926, A3007

Front: Multi-Touch Display,
Front Camera

A2926, A3007

Back Housing: Rear Camera, Microphone,
Smart Connector




A2926, A3007

Top Side: Power/Sleep/Wake Button, Microphone,
Speakers




A2926, A3007
Left Side: Microphone



A2926, A3007

Right Side: Wireless Charger for Pencil, Volume Up/
Down Buttons



A2926, A3007
Bottom Side: USB-C Connector, Speakers

