

A3355, A3356

Front:
Multi-Touch Display,
Front Camera



A3355, A3356

Back Housing:
Rear Camera,
Microphone




A3355, A3356

Left Side: Smart Connector




A3355, A3356

Top Side: Power/Sleep/Wake Button, Speakers



A3355, A3356

Right Side: Volume up/down buttons,
Microphone



A3355, A3356

Bottom Side: USB-C Connector,
Speakers

