



A3389
Bottom



A3389

Front - Status Light Indicator,
SD Card Slot, Two USB-C Ports



A3389

Rear - Power Button, Headphone Jack, HDMI Port, Two USB-A Ports, A/C Inlet, Gigabit Ethernet Port, Four USB-C Ports



A3389
Left



