

TFAH-US6B Tune-Up Procedure

Gain for the TFAH-US6B is set at the factory and no provisions are made for user accessible controls. Output power is a function of the input power and the fixed gain of the TFAH-US6B.

The user should provide an input signal that will produce an output power not exceeding the levels included in the product data sheet for the TFAH-US6B remote.