
Test Setup photographs (DTS)

EUT Position: X-axis




EUT Position: Y-axis



EUT Position: Z-axis



Test Setup Photo of Radiated Measurement



Test Setup photographs of Conducted Emissions

