Model: 17Z90TR Series

EUT Internal Photos

Figure 22 Internal View (With Keyboard)



Figure 23 Internal View




Figure 24
Battery, Front View



Figure 25 Battery, Back View




Figure 26 SUB Board, Front View




Figure 27 SUB Board, Back View




Figure 28 Main Board, Front View (WLAN Combo Card Location)




Figure 29 Main Board, Back View




Figure 30 WLAN Combo Card View



Figure 31 WLAN Combo Card, Without Shield and Back View




Figure 32 WLAN Combo Antenna Position








Figure 34 WLAN Combo Antenna, Back View



Model: 17Z90TR Series

Figure 35 LP170WQ2, LCD Panel, Front View



Figure 36 LP170WQ2, LCD Panel, Back View



Figure 37 LP170WQ2, LCD Panel, Label View

Model: 17Z90TR Series



Figure 38 CPU View




Figure 39 RAM View

