

PARTS LIST

REFERENCE	PART TYPE		REMARK
C1	CER, CAP.	4PF	NPO
C2	CER, CAP.	20PF	NPO
C3	CER, CAP.	.01UF	
C5	CER, CAP.	1000PF	
C6	CER, CAP.	12PF	NPO
C7	CER, CAP.	.1UF	
C8	CER, CAP.	.1UF	
C9	CER, CAP.	.1UF	
C10	CER, CAP.	.01UF	
C11	ELE, CAP.	10UF	10V
C12	CER, CAP.	.1UF	
C13	CER, CAP.	.047UF	
C14	CER, CAP.	.1UF	
C15	CER, CAP.	.02UF	
C18	ELE, CAP.	47UF	10V
C19	CER, CAP.	.1UF	
C20	CER, CAP.	5.6PF	
C21	ELE, CAP.	47UF	10V
C22	CER, CAP.	.01UF	
C23	ELE, CAP.	10UF	10V
C24	CER, CAP.	.1UF	
C25	CER, CAP.	20PF	VAR.
C26	CER, CAP.	1000PF	
C27	ELE, CAP.	10UF	10V
C28	CER, CAP.	.1UF	
C29	CER, CAP.	.1UF	
C30	CER, CAP.	.1UF	
C31	CER, CAP.	4700PF	
C32	CER, CAP.	.1UF	
C33	CER, CAP.	1000PF	
C34	CER, CAP.	.1UF	
C35	ELE, CAP.	10UF	10V
C36	CER, CAP.	39PF	NPO
C37	CER, CAP.	39PF	NPO
C38	CER, CAP.	1000PF	
C39	CER, CAP.	1000PF	
C40	CER, CAP.	33PF	NPO
C41	CER, CAP.	1000PF	
C42	CER, CAP.	180PF	
C43	CER, CAP.	12PF	NPO
C44	CER, CAP.	56PF	NPO
C45	CER, CAP.	68PF	NPO
C46	CER, CAP.	.01UF	
C47	CER, CAP.	1000PF	