

Operation description

1. Connect to computer Use the USB or 3.5mm stereo audio cable.
- Connect to iPod, MP3 or CD player Use the 3.5mm stereo audio cable.
- Connect to stereo system Use the 3.5mm stereo Y-Type patch cable.
2. Connect the 9V AC adapter, then plug the other end into a standard AC outlet.
The power indicator lights. For USB connection, the AC adapter to the transmitter is not needed
3. Slide to **Line** for connecting to a stereo device, or to **USB** for connecting to a computer
- 4.. Turn on the audio source and stereo system. The transmitter and receiver link automatically, and the power indicator of the receiver lights.
5. The transmitter has 8 channels. If you cannot hear clear sound or the receiver's power indicator does not light, press **CH** repeatedly to select a channel with clear sound.
6. Adjust the audio source's volume to the desired level.
7. To connect to a PC, open the Sound and Multimedia control panel and select USB Audio Device from the Audio tab. To connect to a Mac, select USB Speakers as your audio output.
8. When you change the music source from Line to USB and there is no sound, try restarting your music application (such as Windows Media Player).
9. When you unplug the audio cable or USB cable and plug it again, sound may be lost for 3-5 seconds.
10. Connect the AC adapter to the transmitter only after connecting to an audio source.
11. Unplug the AC adapter from the AC outlet before unplugging it from the transmitter or receiver.