



Windows Hello camera
Caméra Windows Hello
Cámara de Windows Hello



Power button
Bouton d'alimentation
Botón de encendido



USB-C Thunderbolt™4
Charging capable
Capacité de rechargement
Compatible con carga



Studio Mics
Micros de studio
Micrófonos de estudio



Surface Connect port
Port Surface Connect
Puerto Surface Connect




USB-A



Front-facing camera
Caméra à l'avant
Cámara frontal



Headphone jack
Prise de casque
Conexión de auriculares



support.microsoft.com

 windows.com/accessibility

 surface.com/repairability

 **Microsoft Surface Laptop**

Model 2035
©/TM/®2024 Microsoft

