









This EUT could not be connected to a PC as a data transfer function
Please refer the user's manual, it is not belongs to a Computer Peripheral.