

Test setup photos of 810-00012-00


1. Conducted Emission Test setup

Charged by PC via a USB cable mode



2. Radiated Emission Test (Blow 1GHz)


Transmitting mode



Charged by PC via a USB cable mode



Connect to i-touch via a talk cable playing 1 KHz/0dB audio signal mode:



3. Radiated Emission Test (Above 1GHz)

Transmitting mode

