

What's in the box

1 AirTV™



2 Power Cable



What's needed

HDTV Over-The-Air antenna with included coaxial cable*



Sling Television™ app—
free to download

*Visit airtv.net/antennas for more information

airtv.net

Watch all your local Over-The-Air television. Anywhere.

Federal Communications Commission Notices

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Device must be installed at least 20cm (8 inches) from typical person locations per FCC RF Exposure guidelines. Changes or modifications to this device may void your authority to operate this equipment. Operation in the band 5150-5250 MHz is only for indoor use.


Copyright ©2015 EchoStar Technologies, L.L.C. All rights reserved. AirTV and the AirTV logo are trademarks of EchoStar Technologies, L.L.C. Other products and companies mentioned are the trademarks of their respective owners and not of EchoStar, Inc. Warranty, safety, regulatory, and legal information can be found at airtv.net/warranty. Part Number 208323

AirTV™

Quick Start Guide

DESIGNED FOR

sling
TELEVISION



100mm

110mm

320mm

110mm

180mm


Before you start

Place your HDTV Over-The-Air antenna in a location that can best receive signals such as a window. You may need to adjust the antenna for optimal performance later, so it's best not to permanently mount it just yet. For more information on ideal antenna placement in your home, visit airtv.net/antennaplacement.



1 Connect AirTV™ to your antenna


Connect your AirTV to your antenna via coaxial cable.



2 Connect an Ethernet cable (optional)


This step is only needed if you wish to provide your own Ethernet cable for a wired network setup.

If you plan to connect to your AirTV using WiFi, you can skip this step.



3 Connect the power cable

One or more lights should start blinking on the front of the AirTV, once the power cable is properly connected.



4 Set up your AirTV

airtv.net/setup

To complete setup, visit the above link on your computer or mobile device and follow the instructions.



? Need more help?

We're here for you.

For more information and a step-by-step setup video, visit airtv.net/setupvideo.

Find a treasure trove of helpful articles at support.airtv.net

Stay connected with AirTV

Twitter
[@AirTVUs](https://twitter.com/AirTVUs)

Facebook
facebook.com/USAirTV