

1. External Photograph of EUT**Brand Name: Chicony / Model Name: C100**



Brand Name: Chicony / Model Name: C100





Brand Name: Chicony / Model Name: C100





Brand Name: Chicony / Model Name: C100



**2. Photograph of Accessory****Brand Name: Chicony / Model Name: C100****List of Accessory:**

Specification of Accessory		
AC Adapter 1	Brand Name	Sunny
	Model Name	SYS1448-1005-W2
AC Adapter 2	Brand Name	Sunny
	Model Name	SYS1448-1005-W2E
Battery	Brand Name	CB-170
	Model Name	CB-170
USB Cable	Brand Name	VSO
	Model Name	E189529
HDMI Cable	Brand Name	E&V
	Model Name	E301195

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Chicony / Model Name: C100



Brand Name: Chicony / Model Name: C100

Adapter 1



Brand Name: Chicony / Model Name: C100

Adapter 2



Brand Name: Chicony / Model Name: C100

Battery

