

Front of Penal



Antenna
Position

Antenna
Position


Back of Penal




Internal of EUT



Front of motherboard



Back of motherboard



Front of RF Module



Front of RF Module-1



Back of Module



Antenna

