

---

# INTERTEK TESTING SERVICE


---

## Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

Adaptor: VT05EUS05100

(Front View)



---

# INTERTEK TESTING SERVICE

---

## Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

Adaptor: VT05EUS05100

(Back View)




---

## INTERTEK TESTING SERVICE

---

Configuration Photographs  
Radiated Emissions (30MHz - 1GHz)  
Adaptor: A318-050100W-US2  
(Front View)



---

## INTERTEK TESTING SERVICE

---

### Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

Adaptor: A318-050100W-US2

(Back View)



# INTERTEK TESTING SERVICE

---

## Configuration Photographs

### Worst Case Radiated Emissions (Above 1GHz)

#### (Front View)



# INTERTEK TESTING SERVICE

---

## Configuration Photographs

### Worst Case Radiated Emissions (Above 1GHz)

#### (Back View)



---

# INTERTEK TESTING SERVICE

---

**Configuration Photographs**

**Conducted Emissions**

**Adaptor: VT05EUS05100**

**(Front View)**



# INTERTEK TESTING SERVICE


---

## Configuration Photographs

### Conducted Emissions

Adaptor: VT05EUS05100

(Left View)



---

# INTERTEK TESTING SERVICE

---

## Configuration Photographs

### Conducted Emissions

Adaptor: VT05EUS05100

(Right View)



---

# INTERTEK TESTING SERVICE


---

**Configuration Photographs**

**Conducted Emissions**

**Adaptor: A318-050100W-US2**

**(Front View)**





---

# INTERTEK TESTING SERVICE

---

## Configuration Photographs

### Conducted Emissions

Adaptor: A318-050100W-US2

(Right View)

