VM928HD VM928-2HD Full Color Pan and Tilt





For more support information







TECHNICAL SPECIFICATIONS

Quick start guide

vtech

Frequency control	Crystal controlled PLL synthesizer	
Transmit frequency	Baby unit: 2.405-2.475GHz	
Channels	32	
LCD	5" Color LCD (IPS 1280x720 pixels)	
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.	
Power requirements	Parent unit: 3.7V 5000mAh, 18.5Wh Lithium-ion battery Baby unit power adapter: Output: 5V DC @ 1A	

Parent unit power adapter: Output: 5V DC @ 2A



Recycle this product when you are done with it. For more information, scan the QR code or visit vtechphones.com/recycle.







2024 VTech Communications, Inc. All rights reserved. 7/24. VM928-XHD_QSG_V4.

Press \bigoplus to zoom in or out.



IMPORTANT SAFETY INSTRUCTIONS

The applied nameplate is located at the bottom of the baby unit's base When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- Follow all warnings and instructions marked on the product. CAUTION: Do not install the baby unit at a height above 6.5 feet
- 4. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be
- used as such. This product is not intended for use as a medical monitor. Do not use this product near water, for example, near to a bath, sink, swimming pool or shower.
- CAUTION: Use only the battery provided (if applicable). There
 may be a risk of explosion if a wrong type of battery is used for
 the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery in fire or a hot oven, mechanically crushing or cutting the battery can result in an explosion. Leaving the battery in an extremely high temperature ment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremel ow air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the information in **The RBRC seal**.
- Use only the power adapters included with this product. Incorrect power adapter polarity or voltage can seriously damage the product.
- Power adapter information: Baby Unit Output: 5V DC 1A VTech Telecommunications Ltd. Model: VT05EUS05100
- Jiangxi Jian Aohai Technology Co., Ltd. Model: A318-050100W-US2 Parent Unit Output: 5V DC 2A Model: VT07EUS05200
- Jiangxi Jian Aohai Technology Co., Ltd. del: A938-050200W-US1
- Rechargeable battery information: 3.7V 5000mAh, 18.5Wh Lithium-ion Battery Zhuhai Great Power Energy Co., Ltd. Model: GSP806090-5Ah-3.7V-1S1P
- The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, un-10. For pluggable equipment, the socket-outlet (power adapted
- should be installed near the equipment and should be easily 11. Unplug this product from the wall outlet before cleaning not use liquid or aerosol cleaners. Use a damp cloth fo
- 12. Do not modify the power adapters or replace with other adapt
- ers, as this causes a hazardous situation. 13. Do not allow anything to rest on the power cords. Do not insta this product where the cords may be walked on or crimped. 14. This product should be operated only from the type of power
- source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or 15. Do not overload wall outlets or use an extension cord
- 16. Do not place this product on an unstable table, shelf, stand or other unstable surfaces. 17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect

placing the product on a soft surface such as a bed, sofa or rug

- This product should never be placed near or over a radiator or heat source. 18. Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Disassembling or removing parts of the product other than via the battery door (if applicable) may expose you to dangerous voltages
- or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used. 20. You should test the sound reception every time you turn on the nits or move one of the components
- 21. Periodically examine all components for damage 22. There is a very low risk of privacy loss when using certain elec ronic devices, such as baby monitors, cordless telephones, etc To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically b powering off and then powering on the units, and power off the baby monitor if you are not intending to use it for some
- 23. Children should be supervised to ensure that they do not play 24. The small parts of this monitor can be swallowed by babies or
- small children. Keep these parts out of reach of children. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


SAVE THESE INSTRUCTIONS

Use and store the product at a temperature between 32°F (0°C) and 104°F (40°C).

- Mishandling batteries can cause burn, fire or explosion hazards. Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- Do not expose the product to extreme cold, heat or direct sunight. Do not put the product close to a heating source.
- Warning—Strangulation Hazard—Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9m) away). Do not remove warning label on the adapter Never place the camera unit(s) inside the baby's crib or playper
- Never cover the camera unit(s) or parent unit with anything such as a towel or a blanket. Other electronic products may cause interference with your
- camera unit. Try installing your camera unit as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.
- Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless devices) Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted
- ardiac pacemakers. Supported by the U.S. Food and Drug Pacemaker patients Should keep wireless devices at least six inches from the
- Should NOT place wireless devices directly over the pacemaker such as in a breast pocket, when it is turned ON.
- WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices. Electromagnetic fields (EMF)

electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used


WHAT'S IN THE BOX




CONNECT THE BABY MONITOR

■NOTES

- The rechargeable battery in the parent unit is built-in. Use only the power adapters supplied with this product.
- Make sure the parent unit and the baby unit are not connected to the switch controlled electric outlets.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of the parent unit and the baby unit, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the
- adapters may not properly connect to the outlets. Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.
- To maintain compliance with the FCC's RF exposure guidelines, place the baby unit at least 20cm from nearby persons.




OVERVIEW - BABY UNIT



Charge the parent unit battery before use


CONNECT THE BABY MONITOR (CONT'D)




The barrery reof indicates the barrery status (see the following table).			
BATTERY INDICATORS	BATTERY STATUS	Action	
The screen displays and and I also ii ii ii ii ii ii ii ii ii	The battery has very little charge and may be used for	Charge without interruption (about 30 minutes).	


С. Т only a short time The battery icon becomes The battery is fully charged. To keep the battery charged, connect it to AC power when in use. solid .


POWER ON OR OFF THE BABY MONITOR











3 Positioning the baby monitor

① CAUTION


The default volume of your parent unit is level 3, and the maximum volume is level 5. If you experience feedback noise from your baby monitor while positioning:

Make sure your baby unit and parent unit are more than 3 feet (1 meter) apart, OR Lower the volume of your parent unit.

STATUS CHECK

Once you power on both your baby unit and parent unit, your parent unit displays image from the baby unit, and the **LINK** LED light turns on.


The green LED light of the baby unit turns on.



BASIC OPERATION - PARENT UNIT


Adjust speaker volume


Press - VOL/ VOL + to adjust your parent unit speaker volume. It determines the volume of sound transmitted from your baby unit.





Talk to your baby via the baby unit

- When the icon displays on screen, speak to your parent unit. Your voice is transmitted to the baby unit.
- When finish talking, release the **TALK** key and hear your baby again.










unit. You can still hear sound from the


- turn off the screen.
- turn on the screen again.




Turn on/off the parent unit screen

You can turn on or off the parent unit screen without powering off the parent


- Press **POWER** on the parent unit to
- Press any keys on the parent unit to






Use the menu

Press MENU to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.



- Press ∧, ∨, <or>
 to scroll among the menu options.
- Press **SELECT** to select an item, or to save a setting.
- Press TALK to return to the live video.
- Press to go to the **Help & info** page.




- Battery LED light 3- level sound indicator
- ⊕ Press to zoom in/out. When in the main menu.
- press to go to the Help & Info page. TALK <u>Press and hold</u> to talk to


· While in a submenu,

- MENU/SELECT
- choose an item, or save a
- VOL/ VOL + Increase or decrease parent unit's volume.
- Press to enter the main While in a menu, press to

Overview - Parent unit



- 11 Speaker 12 POWER key
- 13 Power jack Force reboot the parent
 - 15 Stand



- Microphone
- 2 Camera lens
- 3 Light sensor
- LED indicator Infrared LEDs


(I) Power switch

- Antenna Speaker
 - Wall mount slots 11 Pair button

Power iacl

NEED HELP?

For operations and guides to help you using your video monitor, and for latest information and supports, go and check the online help topics and online FAQs.



frame it. Tap the notification to trigger the redirection of the online help. - If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.



VM928-2HD

PARENT UNIT ICONS

Main menu icons

■ Notes

Main menu





Baby unit 1 in Single mode



- Baby unit 2 in Single mode
- Patrol mode

Melodies and soothing sounds

Melodies and Soothing Sounds


• Select play all melodies, or play one of the



Alerts - Sound, motion and temperature







• Select sound Sensitivity level. • Turn on/off Sound Detection Alert. • Turn on/off Auto Wake Up function.

(See Sound Detection and Auto Wake Up

section) Motion

- Turn on/off Motion Alert.
- · Select motion Sensitivity level. (See Motion Detection section)

Main menu

Temperature

- Turn on/off Temperature Alert. Set the parent unit to beep whenever the room temperature detected by the baby unit falls outside of the set temperature
- Select Minimum temperature for alert range.
- Select Maximum temperature for alert • Select temperature **Format**.

Set temperature display in Fahrenheit (°F)

Parent unit settings

Turn on/off Dim Mode.

or Celsius (°**C**).

Baby unit settings



• Turn on/off Low Battery Alert Tone. Set the parent unit to beep when the battery is low.

• Turn on/off baby unit's Status LED.

Adjust baby unit's speaker Volume.

• Turn on/off No Link Alert Tone. Set the parent unit to beep when the link between the parent unit and the baby unit

Status icons

Current view status The baby unit number that is being viewed


- Single CAM mode. Patrol mode (* For VM928-2HD only).
- Split mode (* For VM928-2HD only). Split mode (* For VM928-2HD only)
- Patrol mode (* For VM928-2HD only) Night vision feature is activated automatically.
- Motion alert is turned on.
- Melodies or soothing sound are turned on.

Parent unit speaker is muted.

Sound detection alert is turned on.

Temperature alert is turned on.

Real-time temperature indicator Battery status indicator



and needs charging.



Displays when sound is detected at a baby

Baby unit detects temperature exceeds the



Baby unit detects temperature is lower than



Use your smartphone or mobile device to access our online help.

- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and
- You can also call our Customer Support at 1 (800) 595-9511 [in US] or 1 (800) 267-7377 [in Canada] for help.

