

User's Guide

Gemini-M1

RF Keyboard & Mouse Combo

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

You are cautioned that any change or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.


The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Quick User's Guide for Gemini M1-Wireless Keyboard and Wireless Optical Mouse combo


Thank you for choosing our Gemini M1. This user's guide will lead you to get start right away. Please follow the instructions below:

I. Components and Features:

1. Features:
 - Wireless Multimedia Keyboard + Wireless Optical Mouse
 - Scroll Wheel
 - Ergonomic Design
 - Security ID: 256 set ID
2. Package Contents:
 - Wireless Optical Mouse
 - Wireless Multimedia Keyboard
 - RF Receiver
 - 5 AA Batteries
 - UP Adaptor (UP interface only)
 - User's Guide
3. Hardware Installation:
 - Insert the Batteries
 - Refer to diagram inside the battery compartment



III. ID Set



Reset ID before using

- Step 1: Plug the RF Receiver in your computer (PS2 port or USB port). For best result, please plug the RF Receiver in the Front Side USB Port.
 - Step 2: Push the connect button on the RF Receiver. The Signal LED will start to blink.
 - Step 3: Push the connect button on the back of the Wireless Mouse. Please note that this step must be completed within 8 seconds after Step 2.
 - Step 4: When the RF Receiver and the Wireless Mouse are connected, the Signal LED will blink faster for a while, it means mouse ID setting has been completed.
 - Step 5: Push the connect button on the back of the wireless keyboard.
 - Step 6: Push the connect button on the RF Receiver. The Signal LED will start to blink. Please note that this step must be completed within 8 seconds after Step 5.
 - Step 7: Click "Space" key. Once the receiver and the wireless keyboard are connected, the Signal LED will blink faster for a while. It means all ID setting has been completed.
- If the Wireless Mouse does not work properly, please go back to Step 2. (In case, the ID is used by other users or devices, please just repeat this reset procedure.)

59.68

ione

Hot keys explain & Programmable functions menu

Hot keys explain



- Refresh : Refresh the current browsing web page
- Favorites : Open My favorite panel
- Stop : Stop downloading current web Page
- Search : Open IE Search panel
- Back : Back to the last page on Internet browser
- Forward : Forward to the next page on Internet browser
- Stop : Stop Playing CD/VCD/DVD player
- Play/Pause : Play or pause CD/VCD/DVD player
- Previous Track : Instruct the CD/VCD/DVD player to the previous track
- Next track : Instruct the CD/VCD/DVD player to the next track
- Home : Back to web home page or open IE browser
- Mail : Open Default E-mail application
- Media Select : Turn on the Media player program
- Volume Down : Turn the volume down
- Mute : Mute the volume
- Volume Up : Turn the volume up

TROUBLE SHOOTING GUIDE

Symptom	Possible Reason	Remedy
Can't recognize the device or the device can't work.	Device can't connect to receiver	Follow the step of ID reset to connect device and receiver again.
Device can't work after the driver is installed.	The Driver is installed or removed.	Reboot the PC.
This function of software is not work.	Function error.	Reinstall the software or refer to the User's Guide.

★ You need install Multimedia key driver in Windows 98SE. Download the driver at "www.ione.com.tw"

Itron Technology Inc.

www.ione.com.tw
ione@ione.com.tw

©2003 Ione. All rights reserved. Ione, the Ione logo, and product names referred to herein are the registered trademarks of Itron Technology Inc. All other trademarks are the property of their respective owners.