

# **FORWARD ELECTRONIC CO.,LTD**

## **User's manual**

1. Insert AAA batteries into the remote unit.
2. Press any key will send rf data by 27.045MHZ.
3. Troubleshooting.

Remove batteries, reinstall batteries.

15.19 "This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2)  
this device must

15.21 "Changes or modifications are not expressly  
approved by the manufacturer could void the user's  
authority to operate the equipment."