User manual

1. Move slide cover to take out receiver and pack one triple A batteries into MOUSE (the transmitter)。
2. When PC is in turned-on state, please use MOUSE to aim at the receiver which has been installed in the PC。
    (1) Press ID switch of receiver in the USB of PC。
    (2) Then，press the ID button on the MOUSE to pass the signal to receiver。
3. When RF wireless MOUSE is set up， it is still without reaction or without signals。
    (1) Repeat the direction of Step 2-(1) and 2-(2)。
    (2) Confirm battery have been installed correctly。
4. Compatibility: The operating system is suitable for Windows 2000 and Windows XP。

Warning：
   1.15.21 "Change or modifications are not experessly approved by the manufacturer could void the user's authority to operate the equipment。"
   2.15.19 "This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions：
       （1）.This device may not cause harmful interference，and
       （2）.this device must accept any interference received，including interference that may cause undesired operation。"