



FlexWave™ PRISM
Remote Unit
Right View




FlexWave™ PRISM
Remote Unit
Left View



FlexWave™ PRISM
Remote Unit
Rear View



FlexWave™ PRISM
Remote Unit
Top View



FlexWave™ PRISM
Remote Unit
Bottom View