


## DUK-100

### USB 10/100 Ethernet Adapter

**Installation Steps** G

1. Plug your USB cable in to USB port of the Ethernet Adapter.
2. Plug the other end of your USB cable in to the USB port of your PC.
3. Plug in the UTP cable to the "RJ45" socket of your USB Ethernet Adapter.



#### 4. Verifying your connection

4. Please select Floppy item and put driver diskette into the Floppy.
5. Click **Next** button.
6. Windows driver file search for the device **USB Ethernet Adapter**.
7. Click on the **Next** button.
8. Windows copying file.
7. Click on the **Finish** button.
8. Restart your computer click "Yes" button.

After the complete install the drivers for the USB Ethernet Adapter.

#### Windows 98 Driver Installation

### Quick Installation

#### Note:

PW: Power  
LK: Link  
RX: Receive  
TX: Transmit

1. Boot the system from Windows 98. Windows will auto-detect the existence of the USB Ethernet Adapter.
2. Now Windows will begin the **Add New Hardware Wizard** and search for new drivers for "USB Ethernet Adapter". Click on the "Next" button.
3. Select searching the most fit of driver & suggested to use. Click

312B2DU00001