

MID-android4.0

Instruction

Please read the precautions and important tips in the instructions before use.

Catalog

CHAPTER ONE OVERVIEW
1-1 APPEARANCE
1-2 BUTTONS
1-3 OPEN AND SHUT DOWN
1-4 OPEN AND CLOSE STANDBY MODE
1-5 LOCK AND UNLOCK THE SCREEN
1-6 HOMEPAGE INFORMATION COLUMNS
1-7 TEXT INPUT
CHAPTER TWO: INTERNET
2-1 BROWSER
CHAPTER THREE: APPLICATION
3-1 CAMERA
3-2 PHOTOS
3-3 VIDEO PLAYER
3-4 MUSIC
3-5 CALENDAR
3-6 CALCULATOR
3-7 DOCUMENT BROWSERS
3-8 APPLICATION INSTALLATION
3-9 VIDEO OUTPUT
3-10 SIMULATION GAME
3-11 DOWNLOADS
3-12 E-MAIL
CHAPTER FOUR: SYSTEM SETTING
4-1 SOUND SETTING
4-2 INTERNET SETTING
4-3 DISPLAY SETTING
4-4 APPLICATION SETTING
4-5 DATE & TIME SETTING
4-6 LANGUAGE AND INPUT SETTINGS
CHAPTER FIVE: OTHERS
5-1 SPECIFICATION
5-2 NOTES

10A03

1

2

Agenda: list all events click to read the details.

In any views, when you switch to other date, week or month, all can be back to today or week or month now by touching <today> button.



You can also click here to search task memo, edit, notation and share.

3-6 Calculator

Touch here in the application list to get into the calculator.



3-7 Document browsers

Touch here in the application list; it supports the files mutual copy in this two places internal memory and SD card.



Touch the button when it turn to yellow, you can edit the file.

Edit

Touch this to edit the file including cut/copy/paste/delete

Copy, choose one file in the list, click this to copy when show the

Then click this to choose where to put the file, and then click this to paste.

Delete, choose one file that click here to delete.

3-8 Application installation

Touch here in the application list, it will install, unload the APK files automatically.

It searches the APK file from **/mnt/flash** or **/mnt/sdcard**



Touch the selected APK application directly for installation and unloading
3-9 Video output

Touch here in the application list; choose the resolution of the video output.



System has 720P and 1080P two kind of resolutions.

3-10 Simulation Game

In the application list click here to connect the handle to the game, there will be AC, PS, MD, GBA, FC APK file in the Motin Game.

Different equipment installs different simulator



Handle

: Space, : back, : select, : start

, , , ,

Different keys set different in the game

3-11 Downloads

Chapter One Overview

1-1 Appearance

Picture for reference only. Please subject to specific products.



1-2 Buttons

Power button

Long press the button about 2-3 seconds to open the screen.

When open the tablet, short press this to enter the off-screen state and short press again to light up the screen.

Volume

this to adjust the volume

Set up

This key to set up the applications

1-3 Open and shut down

Open

Long press the power button on the right side, A9 sign and pictures will show up in turn until to the interface.

Shut down

Long press the power button , then the screen shows <would you like to shut down>, press <sure> to shut down.

In charging state, when the tablet is off, press the right upper "power button" it will shows "charging" figure, once again to click "power button", the equipment will be opened.

1-4 Open and close standby mode

Open the standby mode

In boot mode, you can tap the power button on the upper right side of the tablet, the system will into the stand by mode which can save power.

Close the standby mode

In the stand by mode, light tap of the power button on the right side to wake up the device, enter the normal state.

1-5 Lock and unlock the screen

Lock

You can set up the sleep time in the system of <display>.

The system will sleep automatically and lock the screen to the standby mode if without any inactivity when reaches the preset of standby time.



3

Click here in the application list; you can preview the downloading or done document contents.



Click download file to stop or delete the download contents.


3-12 E-mail

Require the internet support before using e-mail, if there are problems in network supporting, please contact your network operator.

Add account

If you are the first time to use email, get into a mailbox interface directly to set up an account according to instruction.

If you want to add more mailboxes, click <Settings> on the top of the page to add more mailboxes, and then select <add account>.



Draft e-mail

In <inbox> page, you can click on the right page top to draft mail quickly.

In the draft mail page, you can:

Add mail recipients quickly.

Enter the recipient address in recipient input box or click on the <contact> in the contact list of recipients to choose mail address; you can copy/close to send input address.

Write email subject and text content (the text area support copy, shear operation);

Add attachment

Add attachments from the document management, when it succeeds, the name will show one <New e-mail> page; you can click to select to open or remove them.

Reply, forward mail

Click the right page preview area of the toolbar <reply> <reply all> or <forwarding> choices.

The basic operation is same with the draft e-mail.

Chapter four: System setting

Click here to enter the system setting interface.

4-1 Sound setting

Sound settings, click this to sound setting page. You can choose mute switch which can get more detailed settings if you need. Click the <volume setting> can set up the notice, the media and the alarm of volume and choose the prompt operation sound and the bell and software disk boot switch voice.

4-2 Internet setting

This setting module includes: the wireless local area network Settings

The wireless local area network Settings


Unlock

Move the sign to unlock, show as below.

Drag this to unlock the screen and enter the application interface.



1-6 Homepage information columns



Google shortcut key Menu shortcut key

Back Host interface Recent search

1-7 Text input

When use the tablet, you can use the virtual keyboard to enter text, numbers, symbols directly by touching screen.

After selecting the Android input method, the default keyboard show as below.



To switch the numbers and letters, please press this .

To switch the capital and lowercase letter, please press this .

Chapter two: Internet

2-1 Browser

Require network support before using a web browser, if there are network supporting problems, please contact your network operator or the service provider.

Tablet's web browser can connect to the Internet via WIFI to satisfy your business and individual network needs.

Please touch this to set up the WIFI so that can use the browser normally. See as picture:



Touch here in the application list to enter the browser pages; the default homepage is the <Recently Viewed> showing recently viewed pages.

Browser supports the following features



4

Open wireless LAN switches, the system will scan available wireless network automatically and display the wireless local area network in the list.

Among them, if the local area networks have the sign behind it, that represents the networks don't need a password, can be connected directly.

This sign represents the network has been encryption, it needs to enter the password to connection. You can choose the network from the list you want, click it to connect directly, also you can click the <advanced> option to set up the <IP> and <agent>, then click <connected to the network>; you can also select <add wireless local area network> to add by hand.

Network notice: open the switch, it will notice if there any open network.

The wireless local area network certificate: the wireless local area network loading and management.

MAC address: to show the MAC address

4-3 Display setting

In this setting, Display Settings contains: wallpaper Settings, dormancy time, brightness, automatic rotating Settings

Wallpaper setting

In the wallpaper setting, you can set up the wall paper and dynamic wallpaper; the wallpaper can be chosen from gallery.

Standby Screen

When the screens in light state a period of time, it will automatically lock to save the power if without any operations.

Brightness

The user can adjust brightness manually to get the lightness you want.

Font size

You can set up the font size according to individual's favorite, there were respectively: small, ordinary, big, huge.

4-4 Application setting

In this setting, you can manage the running services and access rights management and development but only for developers.

Application management

In this setting, it is easy to manage and delete some applications that have been installed.

First, get into the application list, click the <according to name sort> buttons to order the alphabet and number; click the <all> menu to scan the running program or programs that provide by a third party software developers. Click on an application, you can see the application's relevant information to clear the cache, unload programs, clear the default value or forced to stop operation, etc.

Running services

In this setting, you can end and set up some programs that are running

Access management

In this setting, by using the opening or prohibition to manage the applications to access content permissions

4-5 Date & Time setting

In this date and time setting, you can set up your system time and series options.

Time setting

You can use automatic time from the network, to choose the time zone, to set specific date and time and display format in time setting.

4-6 Language and input Settings

Language & Input

You can choose the language you want

Input method

In here the input methods can be set by users, you can add the words in the dictionary or to delete.

Android keyboard

You can set up automatic capital function of opening or closing

10

Enter the URL-touch the input area to get the soft keyboard, then text the URL.

Book mark search- click this to add into the bookmark

Touch this to read the favorite website that collected

Touch this to search the internet

Touch this to add new browser.

Touch this to close the browser

Chapter three: Application

3-1 Camera

Touch this in the application list to enter the camera, the views showed on the screen and you can do the following as picture:



Camera

Click this to get Snap shot.

Setting: to set up white balance, exposure, save, start.

Video

Click this to video and do the relevant operation.

Setting: white balance setting, delay, save, click this to start video

View photos and video

In pictures preview interface, click on the screen to preview photos, also you can set up the pictures to slides.

3-2 Photos

Click here in the application list which including all the pictures.



Click this can classify the pictures by time and place. Click this to enter the camera.

Click this to choose the album to edit or delete.

Click this to enter slides show when you enter the album.

3-3 Video player

Touch this to the Video player.

You can see the Videos in nand and sdcard files.

Chapter five: others

5-1 Specification

Type	Project	Description
System	CPU	Amlogic A8726-M (ARM Cortex™-A9 +Mali 400.GPU+DSP)
	CPU frequency	(ARM Cortex-A9(800M) +GPU(Mali 400M)+DSP(200M)
	Display	10.1" 1024*600 resolution, touching panel
	Memory	DDR3-1G
	Flash	□4GB □8GB □16GB
	Storage Extend	2GB-32GB SD/TF Support
	WiFi	High performance with 802.11b/g
	Camera	300000 Pixels
	G-sensor	360°
I/O Ports	OS	Google Android 4.0
	Mini USB	
	USB-host	
	HDMI standard mini port	
	Charing--DC 9V input	
	Earphone---3.5mm	
Android 4.0 Features	Microphone Port	
	1. Complete redesign of the user interface	
	2. Better organization	
	3. Adjustable font	
	4. Quick Response	
	5. Data Usage View	
	6. Expanded camera feature	
	7. Improved Keyboard	
	8. Better Cut/Copy/Paste	
	9.Better Gmail	
	10.New Calendar with pinch-to-zoom	
	11.Updated Google applications	
	12.Tabbed Internet browser	
	13.Better contact management	
	14.Visual Voicemail	
Internet	Browser	Opera,UCWeb,SkyFire,Dolphin
	online entertainment	Support Online video,online Tv,online Movie,Online Music,Online Radio.
	Office software	WORD, EXCEL, POWERPOINT, PDF, TXT,
	Games	3D Game can be supported by internal 3d accelerate of hardware
Audio playing	Extend	There are more than 20 thousands kind of free software in goole market
	Formats support	Support MP3,WMA,MP2,OGG,AAC,M4A,MA4,FLAC,APE,3GP,WAV formats audio playing and support songs list
	S/N	above 90dB
Video playing	Recording	Support MP3,WMA formats recording
	Formats support	Support AVI (H.264, DIVX, DIVX, XVID), rm, rmvb, MKV (H.264, DIVX, DIVX, XVID), WMV, MOV, MP4 (.H.264, MPEG, DIVX, XVID), DAT (VCD), VOB (DVD), PMP, MPEG, .MPG, FLV (H.263, H.264), ASF, TS, TP, 3GP, MPG .
	Playing	highest 1920X1080

[潘多拉的世界(阿凡达IMAX最新特辑)].The.World.of.Pandora.mov

[红领巾侠].THE.RED.avi

[里约大冒险].RIO.2011.04.07.1080p.预告片.mov

There are some control areas at the bottom after you enter the video player.



3-4 Music

Touch here to the music player. Music can be played by artists or album classification.

This page displays the songs alphabetically.

Click the songs you want to listen and get into selected state to play.

Click on the <now playing> will display being played album page; there will be lyrics shows under the page right.



Play interface: list, random play, repeat

Artists

In the <artist> page, it is sorted according to the artist's initials, click on one, you will open the artist's related album and song list; then you can click songs to play.

Album

The album page shows all albums in the list, sliding it can browse all. Click on the album cover will transfer to the album back automatically. When all music shows, click again on the songs began to play.

3-5 Calendar

Touch this to Calendar, the default page shows the months, click this to the day.

Date views: long press to the events to rebuilt, view, edit, and delete; Click on the blank area can set up new events.

long press the blank area, you can built new events or display/not display the lunar day view.

Week views: Long presses the event to rebuilt, view, edit, and delete events; long press the blank area you can rebuild events or display/not display the lunar weeks view.

Month view: long press date to build new calendar items or display/not display the lunar month view

	ability
Addition all	Video output
	Files reading
	Picture
	Language
Interface	Speaker
	OTG&HOST
	HDMI
	USB
	Charging
Others	Earphone/Video
	TP
	Key Button
	battery
	machine dimension
	Wight
	Gifbox dimension
	dimension

5-2 Notes

Please don't put it in high temperature, moisture or dust place; the tablet pc is not waterproof.

Avoid falling or violent collision. don't violently shake the touch screen, Otherwise, it could lead to damage display unnatural.

If system shutdown automatically, bootable again soon after the shutdown.

please charge the tablet pc regularly if not use it for a long time to avoid the damage caused by the excessive consumption from battery.

Don't disassemble or use alcohol, thinner or benzene class to swab product surface.

Please don't use the tablet pc when driving or walking in the street, otherwise it may lead an accident.

Please choose the appropriate volume, if had tinnitus, please lower the volume or stop using.

This tablet pc use Cortex-A series A9 kernel, and A9 kernel is ARMV7 instruction support. Generally, the software will detect CPU type is ARMV7 (v7l), this is the CPU support instruction set.

Memory space available dishonest nominal for the android system itself takes up part of the memory space and the operation of the program will also take up space if you open them.

Storage capacity that dishonest nominal for android system occupies about hundreds of MB storage capacity, also in order to install the software needs, the system must lay off certain storage capacity, so the actual usable space and nominal space have deviation.

When CPU in high-speed operation, especially in 3D games or in long time playback high-definition video, the fuselage will have the phenomenon of fever.

This operation manual listed photo is for reference only!

The company reserves the right to improve product. You will have prior notice if the product specification and appearance are change.

(© 2011.12 All Rights Reserved.)

FCC Statement:

NOTICE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications made to this equipment not expressly approved by SHENZHEN TSXD TECHNOLOGY CO.,LTD may void the FCC authorization to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. Please see the RF Exposure information. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.