

60P白色模造紙 / 單色黑 / 雙面印刷 / 成型尺寸 : 135x95 mm  
PDD-Kathy


封面H:95mm

封面W:135mm

正面印刷

反面印刷

## SlimStr 8018 2.4Ghz Wireless Keyboard & Mouse Combo



### Quick Guide

Copyright© 2019 KYE SYSTEMS CORP.



Genius web : www.geniusnet.com  
GEMOEMO : www.yoom.com

**KYE Systems Corp.**  
#492, Sec. 5, Chongxin Rd., Sanchoing Dist.,  
New Taipei City 24160, Taiwan  
Tel: 886-2-2995-6645  
Fax: 886-2-2995-6649  
Email:sm@geniusnet.com.tw  
Email:cs@geniusnet.com.tw (Tech. Support)  
http://www.geniusnet.com


**KYE International Corp. (USA & Canada)**  
12675 Colony Street, Chino, CA 91710, USA  
Tel: 1-626-226-2678  
Tel: 1-800-756-4115 (Toll Free Line)  
Fax: 1-626-226-2679  
http://www.geniususa.com  
http://www.geniushop.com




12303053400-A

Figure

- 1 Remove the battery cover from the mouse.  
Install one AA battery into the mouse.



- 2 Remove the battery cover from the keyboard.  
Install one AAA battery into the keyboard.




### Replace Batteries


If the mouse or keyboard does not work properly, then the batteries have lost their charge, so you need to replace them.  
Warning: do not mix or use different types of batteries at the same time.

### Notes on Battery Usage

- When you use the battery, carefully read and strictly observe the Safety Instructions and the notes described below:
  - Different battery types and surrounding temperatures may affect the battery performance.
  - Avoid using batteries in extremely cold environments as low temperatures can shorten the battery life and reduce wireless device performance.
- If you are using a new rechargeable battery or rechargeable battery that has not been used for an extended period of time (batteries that pass the expiry date are exceptions) it might affect the period of time according to local regulations.
- You can use this device. Therefore, to maximize their performance and lifetime, we recommend that you fully charge the batteries and discharge them for at least one complete cycle before use.
- The battery or wireless device may feel warm when using for an extended period of time, remove them from the wireless device to prevent leakage or corrosion.
- Always keep the terminals in a clean state.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to local regulations.



Connect both devices, wait 5-10 seconds  
and you are ready to begin



### Mouse Button Assignments

1. **Left Button:** Provides traditional mouse functions like click, double click and drag.
2. **Magic-Roller:** Scroll the button to surf the Internet and Windows documents.
3. **Right Button:** Provides traditional mouse right click function

### Keyboard function key definition

|          |                |
|----------|----------------|
| Fn + F1  | Media Player   |
| Fn + F2  | Volume -       |
| Fn + F3  | Volume +       |
| Fn + F4  | Mute           |
| Fn + F5  | Previous Track |
| Fn + F6  | Next Track     |
| Fn + F7  | Play/Pause     |
| Fn + F8  | Stop Playing   |
| Fn + F9  | Web / Homepage |
| Fn + F10 | Email          |
| Fn + F11 | My computer    |
| Fn + F12 | My favorite    |

### Definiția cheii funcției tastaturii

|          |                     |
|----------|---------------------|
| Fn + F1  | Player media        |
| Fn + F2  | Volum -             |
| Fn + F3  | Volum +             |
| Fn + F4  | Oprire sunet (Mute) |
| Fn + F5  | Înapoi              |
| Fn + F6  | Înainte             |
| Fn + F7  | Redare / Pauză      |
| Fn + F8  | Oprire redare       |
| Fn + F9  | Browser web / Home  |
| Fn + F10 | E-mail              |
| Fn + F11 | Calculatorul meu    |
| Fn + F12 | Preferatul meu      |

### Дефиниция на клавишната функция на клавиатурата

|          |                       |
|----------|-----------------------|
| Fn + F1  | Мултимедия плеър      |
| Fn + F2  | Ниво на звука -       |
| Fn + F3  | Сила на звука +       |
| Fn + F4  | Без звук              |
| Fn + F5  | Предишна              |
| Fn + F6  | Следваща              |
| Fn + F7  | Възпроизвеждане/пауза |
| Fn + F8  | Звукът е изключен     |
| Fn + F9  | Уеб браузър           |
| Fn + F10 | Имейл                 |
| Fn + F11 | Моя компютър          |
| Fn + F12 | Моя фаворит           |

### Визначення клавішної функції клавіатури

|          |                      |
|----------|----------------------|
| Fn + F1  | Медіа плеєр          |
| Fn + F2  | Гучність -           |
| Fn + F3  | Гучність +           |
| Fn + F4  | Вимк. звуку          |
| Fn + F5  | Попередній           |
| Fn + F6  | Наступний            |
| Fn + F7  | Відтворення/Пауза    |
| Fn + F8  | Зупинити відтворення |
| Fn + F9  | Веб-браузер          |
| Fn + F10 | Електронна пошта     |
| Fn + F11 | Мій комп'ютер        |
| Fn + F12 | Мій улюблений        |

### Klaviatuuri funktsiooniklahvi määratlus

|          |                  |
|----------|------------------|
| Fn + F1  | Meedialeplayer   |
| Fn + F2  | Hellitusveenus - |
| Fn + F3  | Hellitusveenus + |
| Fn + F4  | Vaigistamine     |
| Fn + F5  | Eelmine          |
| Fn + F6  | Järgmine         |
| Fn + F7  | Taasesitus/paus  |
| Fn + F8  | Seiskamine       |
| Fn + F9  | Veebi sirvimine  |
| Fn + F10 | E-post           |
| Fn + F11 | Minu arvuti      |
| Fn + F12 | Minu lemmik      |

### Tastatūras funkcijas tastuņu definīcija

|          |                        |
|----------|------------------------|
| Fn + F1  | Multivides atskaņotājs |
| Fn + F2  | Skalums -              |
| Fn + F3  | Skalums + (skalāks)    |
| Fn + F4  | Klusums                |
| Fn + F5  | Iepriekšējais          |
| Fn + F6  | Tālāk                  |
| Fn + F7  | Atskaņot/pauze         |
| Fn + F8  | Atpūrināt atskaņošanu  |
| Fn + F9  | Tīmekļa pārlūkis       |
| Fn + F10 | E-pasts                |
| Fn + F11 | Mans dators            |
| Fn + F12 | Mans mīļākais          |

### Klaviatūros funkcijos klavišo apibrėžimas

|          |                     |
|----------|---------------------|
| Fn + F1  | Medijos grotuvas    |
| Fn + F2  | Garsas -            |
| Fn + F3  | Garsas +            |
| Fn + F4  | Tylidytis           |
| Fn + F5  | Ankstesnis          |
| Fn + F6  | Kitas               |
| Fn + F7  | Groti/Pauzė         |
| Fn + F8  | Sustabdyti grotuvą  |
| Fn + F9  | Interneto naršyklė  |
| Fn + F10 | El. paštas          |
| Fn + F11 | Mano kompiuteris    |
| Fn + F12 | Mano mėgstamiausias |

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

Symbol for Separate Collection in European Countries  
This symbol indicates that this product is to be collected separately.  
This product is designated for separate collection at an appropriate collection point.  
Do not dispose of it in household waste.  
For more information, contact the retailer or the local authorities in charge of waste management.

### جیتانیم ازین جاخه فیدقی فیدریعت

|          |                       |
|----------|-----------------------|
| Fn + F1  | Media Player          |
| Fn + F2  | Volume -              |
| Fn + F3  | Volume +              |
| Fn + F4  | Mute                  |
| Fn + F5  | Anterior              |
| Fn + F6  | Proximo               |
| Fn + F7  | Reproducir/Pausar     |
| Fn + F8  | Parar Reprodução      |
| Fn + F9  | Navegador de Internet |
| Fn + F10 | E-mail                |
| Fn + F11 | Meu computador        |
| Fn + F12 | Meu favorito          |

### Пернетақта функциясы кілтің анықтауы

|          |                      |
|----------|----------------------|
| Fn + F1  | Мултимедия ойнатқышы |
| Fn + F2  | Дыбыс деңгейі -      |
| Fn + F3  | Дыбыс деңгейі +      |
| Fn + F4  | Дыбысты өшіру        |
| Fn + F5  | Алдыңғы              |
| Fn + F6  | Келесі               |
| Fn + F7  | Ойнату/тоқтатып қою  |
| Fn + F8  | Ойнатуды тоқтатыңыз  |
| Fn + F9  | Мәлғұмат/Үягі        |
| Fn + F10 | Электрондық пошта    |
| Fn + F11 | Менің компьютерім    |
| Fn + F12 | Менің сүйікті        |

### 功能鍵使用說明

|          |       |
|----------|-------|
| Fn + F1  | 影音播放器 |
| Fn + F2  | 降低音量  |
| Fn + F3  | 提高音量  |
| Fn + F4  | 靜音    |
| Fn + F5  | 前一曲目  |
| Fn + F6  | 下一曲   |
| Fn + F7  | 播放/暫停 |
| Fn + F8  | 播放關閉  |
| Fn + F9  | 網路/首頁 |
| Fn + F10 | 打開郵件  |
| Fn + F11 | 我的電腦  |
| Fn + F12 | 我的最愛  |

### 功能鍵使用說明

|          |       |
|----------|-------|
| Fn + F1  | 影音播放器 |
| Fn + F2  | 降低音量  |
| Fn + F3  | 提高音量  |
| Fn + F4  | 靜音    |
| Fn + F5  | 前一曲目  |
| Fn + F6  | 下一曲   |
| Fn + F7  | 播放/暫停 |
| Fn + F8  | 播放關閉  |
| Fn + F9  | 網路/首頁 |
| Fn + F10 | 電子郵件  |
| Fn + F11 | 我的电脑  |
| Fn + F12 | 我的最愛  |

### Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее

Символ за раздѣленіе в Європеекее Странее