


Transmitter

Battery Installation

14




Note: When replacing Transmitter batteries: Do not mix old and new batteries.
Do not mix alkaline, standard or rechargeable batteries. Use alkaline batteries only.

Vehicle

2



Battery Installation




Settings

Setting the Band

3



Battery compartment must be empty to view the 4 band select switch.




IMPORTANT: Make certain the vehicle's 4 Band Select switch matches the setting of the 4 Band Select Switch on the transmitter.

Transmitter

4

Features and Functions




F.C.C. CAUTION:

The manufacturer is not responsible for radio interference caused by unauthorized frequency modification to this equipment. Such modifications could void the user's authority to operate the equipment.

Vehicle

Features and Functions



5





4 Band Select




ON/OFF Switch



Steering Trim*



2 Key-Controlled
Racing Gears



Insert key and turn to
change gears.
Vehicle must be stopped
and body must be removed
to switch gears. (page 8)



2 Wheel Drive

* If vehicle pulls to the left or right during forward driving the Steering Trim may need to be adjusted. Steering Trim Dial is located on the underside of chassis between the front wheels.

Trouble Shooting & Support

Problem - Vehicle does not move or moves slowly.

- Make certain there are fresh batteries in the transmitter and that they have been installed in the correct position.
- Are the (+) and (-) markings on the batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Has the Battery Pack been installed in the vehicle?
- Has the rechargeable Battery Pack been fully charged?
- Are the (+) and (-) markings on the Battery Pack in the same position as the (+) and (-) markings in the Battery Compartment?
- Are the metal contact tabs touching, rusty or dirty in the transmitter?
- Make certain that the vehicle ON/OFF switch is in the "ON" position.
- Make certain the vehicle's 4 Band Select Switch matches the setting of the 4 Band Select Switch on the Transmitter.

Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.

- Make certain there is no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.
- Make certain that the transmitter antenna is fully extended.

Do not return this toy to the store!

We stand behind our product. If you experience difficulty assembling, charging or operating this toy, please call us and let us help.

We're here to help!

Call us toll-free at:

1-866-697-2869

8:00am - 5:00pm E.S.T. Mon-Fri

Or visit us online at: www.newbright.com

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

REF65121