



1. External Photograph of EUT

Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;


Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





Brand Name: Technicolor;


Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)





2. Photograph of Accessory

Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)

List of Accessory:

Specification of Accessory				
AC Adapter 1	Brand Name	HONOTO	Model Name	ADS-50FKI-12 12048EPCU-L
AC Adapter 2	Brand Name	HONOTO	Model Name	ADS-50FKI-12 12048EPG

Remark: For accessories equipped with this EUT, please refer to the following photos.



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)

AC Adapter 1



Brand Name: Technicolor;

Model Name: CGA437TTCH4, CGA437TXXXXX (where X can be alphanumeric, -, or blank)

AC Adapter 2

