

Operation instructions

1. Inserting the battery: Open battery compartment on the side of figure with screwdriver. Lift off the door. Using the battery connector inside the compartment, snap in a 9-volt battery door.
2. To turn the walkie talkie on: move the Vol. switch located on the bottom of the unit to ON position. Adjust the Vol. Switch, till you hear a low hissing background noise, which indicates the unit is working properly.
3. To transmit to another relative walkie talkie: Repeat the same act as above. Put it on your head when you speak to .
4. To turn the walkie talkie off: Move the Vol. switch the Off position, This maintains the battery life.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.