

AERO-M4 HONEYWELL
RADIO BOARD PARTS LIST (GL2.874.020PL)

REV.A

ITEM	GLOCOM/N	DESCR.	PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
1	PCB	GL7.820.001PC	PC Board	ISE_RM REV.3 03/2002		GLOCOM	1	
2	CHP	RFS059.002	IC CHIP	CGY 120	MW6	SIEMENS	2	U1905,2910
3	CHP	RFS058.002	IC CHIP	CMY 210	MW6	SIEMENS	1	U1908
4	CHP	RFS001.002	IC CHIP	INA 02186	INA86	HP	2	U2302,2402
5	CHP	ANS030.002	IC CHIP	AA 103-72	SOT-23-5	ALPHA	1	U1053
6	CHP	PWS203.001	IC CHIP	TK 11280CT-ND	SOT-23L-6	DIGI-KEY	1	U9090
7	CHP	PWT403.001	IC CHIP	TK 11460MTL	SOT-23L-6	TOKO	3	U1303,2305,2405
8	CHP	RFS056.002	IC CHIP	MAAM 12021	SO-8	M/ACOM	1	U2901
9	CHP	RFS057.002	IC CHIP	MC 12095D	SO-8	MOTOROLA	3	U1403,1404,2403
10	CHP	RFS062.002	IC CHIP	SSW -124	SO-8	STANFORD	2	U1906,2930
11	CHP	PWS409.001	IC CHIP	REF 192ES	SO-8	Analog Devices	1	U160
12	CHP	RFS060.002	IC CHIP	PMB 2208R-V12TR	P-TSSOP-24	SIEMENS	1	U1101
13	CHP	RFS051.002	IC CHIP	LMX 2306TMX	TSSOP-16	NATIONAL	1	U1401
14	CHP	RFS015.012	IC CHIP	LMX 2326TM	TSSOP-16	NATIONAL	3	U1301,2301,2401
15	CHP	ANS036.001	IC CHIP	OPA 2340EA	MSOP-8	BURR-BROWN	6	U1001,1002,1003,1004,1005,2002
16	CHP	RFS053.002	IC CHIP	PMB 2411FV1.1GE G	P-TQFP-48	SIEMENS	1	U2000
17	CHP	RFS054.002	IC CHIP	SGA -2486	INA86	STANFORD	3	U0102,1302,1502
18	CHP	PWS210.001	IC CHIP	LP 2952AIM	SO-16	NATIONAL	1	U910
19	CHP	PWS410.001	IC CHIP	LM 2674M-ADJ	SO-8	NATIONAL	1	U10
20	CHP	RFS063.002	IC CHIP	SXA -289	SXA289	STANFORD	1	U1901
21	CHP	RFS061.002	IC CHIP	OPA 340NA	SOT-23-5	BURR-BROWN	2	U2080,2090
22	CHP	RFS023.002	IC CHIP	OPA 353NA	SOT-23-5	BURR-BROWN	1	U1006
23	CHP	ANS024.002	IC CHIP	AD 5322BRM	uSOIC-10	Analog Devices	4	U110,130,140,150

ITEM	GLOCOM/N		DESCR.	PART NUMBER		PACKG.	MANUF	QTY.	LOCATION	S/T
24	CHP	LGS055.001	IC CHIP	SN	65LVDS9637D	SO-8	TI	1	U102	S
25	CHP	LGS056.001	IC CHIP	SN	65LVDS9638D	SO-8	TI	1	U101	S
26	CHP	ANS040.002	IC CHIP	OPA	686N	SOT-23-5	BURR-BROWN	1	U8000	S
27	CHP	PWS209.001	IC CHIP	TK	71633SCLCT-ND	SOT-23-5	DIGI-KEY	7	U30,40,50,60,70,80,90	S
28	CHP	ANS026.002	IC CHIP	AD	7729ARU	TSSOP-28	Analog Devices	1	U120	S
29	CHP	ANS028.002	IC CHIP	AD	7818AR	SO-8	Analog Devices	1	U1505	S
30	CHP	ANS038.002	IC CHIP	LM	79L05ACM	SO-8	NATIONAL	1	U20	S
31	CHP	ANS029.002	IC CHIP	AD	8361ARM	RM-8	NATIONAL	1	U1504	S
32	CHP	ANS039.002	IC CHIP	AD	9850BRS	SSOP-28	Analog Devices	1	U1406	S
33	CRS	FI032.000	CRS		854622 (175MHz)	SAWTEK	SAWTEK	1	U1102	S
34	CRS	VC014.003	CRS		CLV1425ME01	ZVCO	Z-COM	1	VCO2	S
35	CRS	VC013.003	CRS		CLV1455E	ZVCO	Z-COM	1	VCO1	S
36	CRS	FI030.002	CRS		DFC31R54P034BHA	DFC31R54	MURATA	2	RBP1,2	S
37	CRS	FI031.002	CRS		DFC31R64P034BHA	DFC31R54	MURATA	3	TBP1,2,3	S
38	CRS	RF002.002	CRS		SAFU110.6MSA40T-TC11	SAFC130.4	MURATA	1	RBP3	S
39	CRS	RF001.003	CRS		SR1000LSQ3200BY	RESONATOR	TRANS-TECH	2	CRY11,12	S
40	PAS	DI104.001	DIODE		DC16-73	SOT-23L-6	ALPHA	1	DCL1	S
41	PAS	DI110.001	DIODE		BBY52-03W	SOD323	SCEMENCE	6	D353,354,355,356,2301,2302	S
42	PAS	DI107.001	DIODE		MA8047-(TX)	SOD323	PANASONIC	1	D1911	S
43	PAS	DI046.001	DIODE		DL5819	1812	MICROSEMI	1	D11	S
44	PAS	DI097.001	DIODE		MA152WK-(TX)	SOT-23	PANASONIC	1	D2040	S
45	PAS	DI115.001	DIODE		LN1351C-TR (P501CT-ND)	1210	DIGI-KEY	1	ZD1	S
46	PAS	DI069.001	DIODE		ZM4734A	1812	DIODES INC.	1	D12	S
47	PAS	DI109.001	DIODE		ZMV829ATA	SOD323	ZETEX	1	D2401	S
48	PAS	TR003.001	TRAN		MMBT3906	SOT-23	DIODES INC.	6	T1301,1401,2301,2302,2303,2401	S
49	PAS	DI012.001	TRAN		2N7002TA	SOT-23	ZETEX	2	T1052,1972	S
50	PAS	TR065.001	TRAN		BSS84TA	SOT-23	ZETEX	1	T1971	S
51	CNT	485.002	CNT		00-8380-010-003-010	IDC10	ELCO	1	J4	T
52	CNT	482.002	CNT		2009-1511-000 (COAX)	CNN	AEP	1	J1	T
53	CNT	483.002	CNT		2025-1511-000 (COAX)	CNN	AEP	1	J2	T
54	CNT	479.002	CNT		114538 (125pin, 2mm)		ERIN	1	P2	T
55	CNT	480.002	CNT		352115-1 (55pin, 2mm)		TYCO	1	P1	T
56	CNT	484.002	CNT		7210-1511-000 (COAX)	SSMB	AEP	1	J3	T
57	CNT	078.011	CNT		CA-S03-24B-44	PIN3	SAMTEC	2	GTP1,2	T
58	IND	0603002.001	IND		1.5nH (LL1608-FH1N5S)	0603	TOKO	2	L1956,1962	S
59	IND	0603001.001	IND		100nH (LL1608-FHR10J)	0603	TOKO	8	L1375,1960,2001,2006,2007,2051	S
									L2121,2131	
60	IND	0805012.001	IND		15nH (334-1062-1-ND)	0805	DIGI-KEY	1	L1105	S

ITEM		GLOCOM/N	DESCR.	PART NUMBER		PACKG.	MANUF	QTY.	LOCATION	S/T
61	IND	0603010.001	IND		18nH (LL1608-FH18NJ)	0603	TOKO	1	L2030	S
62	IND	0603016.001	IND		22nH (LL1608-FH22NJ)	0603	TOKO	1	L2010	S
63	IND	CP081.001	IND		22nH (LL2012-F22NJ)	0805	TOKO	2	L1926,2921	S
64	IND	0603006.001	IND		27nH (LL1608-FH27NJ)	0603	TOKO	2	L1927,2922	S
65	IND	CP018.001	IND		270nH (1008G-271)	1008	STECO	1	L1442	S
66	IND	0603013.001	IND		33nH (334-1017-1-ND)	0603	DIGI-KEY	1	L2902	S
67	IND	CP016.001	IND		330nH (1008CS-331)	1008	COILCRAFT	1	L1441	S
68	IND	0603003.001	IND		4.7nH (LL1608-FH4N7S)	0603	TOKO	2	L2020,2022	S
69	IND	0805007.001	IND		4.7nH (LL2012-F4N7K)	0805	TOKO	2	L2381,2485	S
70	IND	0603008.001	IND		47nH (LL1608-FH47NJ)	0603	TOKO	7	L1121,1501,1901,1946,2120,2130	S
									L2421	
71	IND	0603012.001	IND		5.6nH (LL1608-FH5N6S)	0603	TOKO	1	L1966	S
72	IND	0603009.001	IND		6.8nH (LL1608-FH6N8J)	0603	TOKO	1	L1969	S
73	IND	OT006.001	IND		68nH (1008CS-680XKBC)	1008	COILCRAFT	4	L1102,1103,2101,2102	S
74	IND	CP019.001	IND		680nH (1008CS-681XKBC)	1008	COILCRAFT	1	L1101	S
75	IND	0603004.001	IND		8.2nH (LL1608-FH8N2J)	0603	TOKO	1	L1311	S
76	IND	0805005.001	IND		82nH (LL2012-F82NJ)	0805	TOKO	1	L1104	S
77	IND	1210008.001	IND		1.5uH (ELJ-FA1R5KF)	1210	PANASONIC	1	L8400	S
78	IND	OT005.001	IND		10uH (LQH4N100K04M00)	1812	DIGI-KEY	5	L1392,1910,2391,2481,9000	S
79	IND	OT012.001	IND		1uH (LQH3C1ROM04M)	1210	PANASONIC	2	L8401,8402	S
80	IND	OT014.001	IND		27uH (TKS5465CT-ND)	D10F	DIGI-KEY	2	L10,12	S
81	IND	1210001.001	IND		3.9uH (NL3225T3R9J)	1210	CAL-CHIP	5	L1361,1461,2321,2451,8040	S
82	IND	1210002.001	IND		33uH (ELJ-FA330KF)	1210	PANASONIC	4	L1360,1460,2322,2452	S
83	IND	PU017.002	IND		PE-53826S	PE-53826S	PULSE	1	L11	S
84	CAP	FLM002.001	CAP		0.01uF Film (ECH-U1H103GB5)	1206	PANASONIC	1	C2401	S
85	CAP	0603039.001	CAP		0.01uF (GRM39X7R103K050AD)	0603	MURATA	36	C1010,1020,1022,1024,1026,1027	S
									C1031,111,1102,113,133,1360,1381	
									C1383,143,1460,1514,1521,153	
									C1961,1982,2015,2110,2322,2331	
									C2452,33,43,53,63,73,8003,8020	
									C8022,83,93	
86	CAP	FLM003.001	CAP		0.022uF Film (ECH-U1C223GX5)	1206	PANASONIC	1	C2301	S
87	CAP	FLM004.001	CAP		0.047uF Film (ECH-U1C473GX5)	1206	PANASONIC	1	C1401	S
88	CAP	0603071.001	CAP		0.047uF (ECJ-1VB1E473K)	0603	PANASONIC	2	C1005,1015	S
89	CAP	0603056.001	CAP		0.1uF (ECJ1VF1H104Z)	0603	PANASONIC	68	C1029,111,121,122,125,126,131	S
									C1371,1375,1382,1394,1395,141	
									C1431,1441,1442,1443,1444,1476	
									C1481,1482,1494,1503,151,162	

ITEM		GLOCOM/N	DESCR.		PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
									C1904,1917,1925,1949,1960,1973	
									C1976,1977,20,2040,2041,2042	
									C2043,2081,2341,2361,2363,2382	
									C2392,2461,2472,2482,2487,2905	
									C2922,30,31,40,50,51,60,61,70,71	
									C80,8001,81,90,9003,9091,9092	
									C9095,91	
90	CAP	TS030.001	CAP		10uF/16V (ECSH1CC106R)	1812	PANASONIC	10	C109,1396,1910,1970,2391,2481	S
									C8002,9000,9090,9093	
91	CAP	0603050.001	CAP		1uF/10V (ECJ1VF1A105Z)	0603	PANASONIC	5	C1331,1437,2335,2444,41	S
92	CAP	08146.001	CAP		2.7uF/6.3V (ECJ-2YB0J275K)	0805	PANASONIC	15	C112,132,1391,142,1483,1492	S
									C152,2050,2079,2080,2084,2094	
									C21,8004,9094	
93	CAP	TS067.001	CAP		22uF/6.3V (ECS-HOJC226R)	1812	PANASONIC	47	C1009,101,1019,102,1021,1023	S
									C1025,1028,103,104,105,106,107	
									C108,110,120,130,1377,1385,1390	
									C140,1432,1484,1491,1495,150,	
									C161,1981,2001,2005,2362,2381	
									C2384,2473,25,35,45,54,55,64,65	
									C74,75,84,85,94,95	
94	CAP	TS069.001	CAP		33uF/16V (ECSH1CD336R)	2220	PANASONIC	6	C12,13,14,15,16,17	S
95	CAP	TS007.001	CAP		33uF/25V (EEJ-L1ED336R)	2220	PANASONIC	3	C1,10,2	S
96	CAP	0603060.001	CAP		0.3pF (C06CF0R3B5UX)	0603	D.L.	2	C2306,2307	S
97	CAP	0603052.001	CAP		0.5pF (C06CF0R5B5UX)	0603	D.L.	3	C1969,2411,2412	S
98	CAP	0603041.001	CAP		1.0pF (ECJ-1VC1H010C)	0603	PANASONIC	3	C1109,2405,2406	S
99	CAP	0603073.001	CAP		1.5pF (PCC1R5CVTR-ND)	0603	DIGI-KEY	10	C1311,1312,1322,1323,1422,1423	S
									C1919,2120,2130,2313	
100	CAP	FLM005.001	CAP		1000pF Film (ECH-U1H102GX5)	0805	PANASONIC	1	C2302	S
101	CAP	0603018.001	CAP		1000pF (ECJ-1VB1H102K)	0603	PANASONIC	52	C1101,1384,1393,1412,1413,1415	S
									C1425,1426,1430,1434,1435,1436	
									C1485,1493,1499,1512,160,1903	
									C1907,1926,1930,1931,1936,1937	
									C1948,1972,1979,1980,2006,2030	
									C2075,2076,2083,2093,2101,2104	
									C2364,2402,2424,2425,2474,2902	
									C2903,2917,2923,2926,2976,2977	
									C2979,2980,8000,8016	
102	CAP	0603007.001	CAP		100pF (PCC101ACVTR-ND)	0603	DIGI-KEY	33	C1123,123,124,1326,1376,1449,1502	S

ITEM		GLOCOM/N	DESCR.		PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
									C1516,1902,1906,1932,1938,1947,	
									C2002,2022,2051,2303,2383,2403	
									C2421,2422,2471,2486,2904,2916	
									C2918,2925,2927,7015,7016,7017	
									C8400,8403	
103	CAP	0603053.001	CAP		10pF (PCC100CVTR-ND)	0603	DIGI-KEY	3	C2426,2427,8040	S
104	CAP	0603061.001	CAP		12pF (PCC120ACVTR-ND)	0603	DIGI-KEY	2	C1446,2032	S
105										
106	CAP	0603009.001	CAP		150pF (ECU-V1H151KBV)	0603	PANASONIC	1	C1445	S
107	CAP	0603062.001	CAP		15pF (ECU-V1H150KBV)	0603	PANASONIC	1	C2404	S
108	CAP	0603010.001	CAP		180pF (ECU-V1H181KBV)	0603	PANASONIC	1	C1447	S
109	CAP	0603059.001	CAP		18pF (PCC180ACVTR-ND)	0603	DIGI-KEY	1	C1966	S
110	CAP	0603042.001	CAP		2.0pF (ECJ-1VC1H020C)	0603	PANASONIC	6	C1414,1424,1429,2012,2020,2021	S
111	CAP	0603023.001	CAP		2700pF (ECU-V1H272KBV)	0603	PANASONIC	4	C1003,1007,1013,1017	S
112	CAP	0603063.001	CAP		27pF (PCC270ACVTR-ND)	0603	DIGI-KEY	20	C1106,1107,1332,1333,1334,1438	S
									C1439,1440,2060,2061,2062,2070	
									C2071,2072,2332,2333,2334,2441	
									C2442,2443	
113	CAP	0603066.001	CAP		3.0pF (PCC030CVTR-ND)	0603	DIGI-KEY	2	C2121,2131	S
114	CAP	FLM006.001	CAP		3300pF Film (ECH-U1C332GX5)	0805	PANASONIC	1	C1402	S
115	CAP	0603013.001	CAP		330pF (ECU-V1H331KBV)	0603	PANASONIC	1	C1403	S
116	CAP	0603057.001	CAP		33pF (PCC330ACVTR-ND)	0603	DIGI-KEY	12	C1108,1448,1501,1504,1511,1756	S
									C1757,1758,1900,1901,1909,1962	
117	CAP	0603014.001	CAP		390pF (ECU-V1H391KBV)	0603	PANASONIC	1	C1302	S
118	CAP	0603067.001	CAP		39pF (ECU-V1H390KBV)	0603	PANASONIC	3	C1104,1105,1303	S
119										
120	CAP	0603026.001	CAP		4700pF (PCC472BVTR-ND)	0603	DIGI-KEY	2	C1006,1016	S
121	CAP	0603015.001	CAP		470pF (ECU-V1H471KBV)	0603	PANASONIC	2	C1002,1012	S
122	CAP	0603047.001	CAP		47pF (ECU-V1H470KBV)	0603	PANASONIC	20	C1310,1321,1325,1410,1928,1939	S
									C1946,1950,1968,2311,2312,2319	
									C2320,2410,2430,2431,2901,2913	
									C2930,2943	
123	CAP	0603045.001	CAP		4pF (PCC40CVTR-ND)	0603	DIGI-KEY	10	C1121,1122,1361,1461,1956,2010	S
									C2011,2323,2453,8015	
124	CAP	0603027.001	CAP		5600pF (PCC562BVTR-ND)	0603	DIGI-KEY	2	C1001,1011	S
125	CAP	0603002.001	CAP		560pF (ECU-V1H561KBV)	0603	PANASONIC	2	C8401,8402	S
126	CAP	0603046.001	CAP		6.8pF (PCC6R8CVTR-ND)	0603	DIGI-KEY	6	C2007,2008,2009,2031,2102,2103	S
127	CAP	0603028.001	CAP		6800pF (PCC682BVTR-ND)	0603	DIGI-KEY	2	C1978,2423	S

ITEM		GLOCOM/N	DESCR.		PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
128	CAP	FLM007.001	CAP		6800pF Film (ECH-U1C682GX5)	0805	PANASONIC	1	C1301	S
129	CAP	0603016.001	CAP		680pF (PCC681BVTR-ND)	0603	DIGI-KEY	2	C1927,2921	S
130	CAP	0603005.001	CAP		68pF (PCC680ACVTR-ND)	0603	DIGI-KEY	4	C1369,1469,2321,2451	S
131	CAP	0603070.001	CAP		7pF (GMC10CG7R0C50NT)	0603	CAL-CHIP	1	C1103	S
132	RES	0603004.001	RES		10 (ERJ-3GSYJ100V)	0603	PANASONIC	15	R1017,1027,1391,1491,1961,2001	S
									R2051,2311,2314,2381,2411,2413	
									R2485,2904,8401	
133	RES	0603080.001	RES		100 (ERJ-3GSYJ101V)	0603	PANASONIC	3	R1121,1122,1512	S
134	RES	12002.001	RES		100 (ERJ-8GEYJ101V)	1206	PANASONIC	6	R1915,1916,1917,1930,1940,1950	S
135	RES	0603031.001	RES		120 (ERJ-3EKF1200V)	0603	PANASONIC	1	R2412	S
136	RES	0603032.001	RES		150 (ERJ-3GSYJ151V)	0603	PANASONIC	6	R2941,2943,2944,2946,2947,2949	S
137	RES	0603005.001	RES		18 (ERJ-3GSYJ180V)	0603	PANASONIC	16	R1320,1321,1322,1420,1421,1422	S
									R1505,1508,1530,1967,2315,2316	
									R2414,2415,2416,8000	
138	RES	0603034.001	RES		220 (ERJ-3GSYJ221V)	0603	PANASONIC	11	R1011,1012,1013,1022,1023,1907	S
									R2079,2080,2084,2094,2199	
139	RES	0603096.001	RES		240 (ERJ-3GSYJ241V)	0603	PANASONIC	2	R2312,2313	S
140	RES	0603026.001	RES		27 (ERJ-3GSYJ270V)	0603	PANASONIC	27	R1311,1314,1331,1332,1333,1334	S
									R1381,1411,1414,1437,1438,1439	
									R1440,1445,1481,2302,2304,2332	
									R2333,2334,2335,2402,2404,2441	
									R2442,2443,2444	
141	RES	0603013.001	RES		270 (ERJ-3GSYJ271V)	0603	PANASONIC	1	R2101	S
142	RES	0603014.001	RES		300 (ERJ-3GSYJ301V)	0603	PANASONIC	6	R1504,1506,1507,1509,1966,1968	S
143	RES	0603027.001	RES		33 (ERJ-3GSYJ330V)	0603	PANASONIC	9	R113,133,1375,1415,143,1430	S
									R153,2005,2421	
144	RES	0603016.001	RES		330 (ERJ-3GSYJ331V)	0603	PANASONIC	5	R1003,1004,1007,1008,2901	S
145	RES	0603079.001	RES		39 (ERJ-3GSYJ390V)	0603	PANASONIC	1	R1949	S
146	RES	0603113.001	RES		4.3 (ERJ-3GSYJ4R3V)	0603	PANASONIC	1	R1905	S
147	RES	0603011.001	RES		5.1 (ERJ-3GSYJ5R1V)	0603	PANASONIC	13	R1033,1101,1921,1924,1925,1942	S
									R1952,2361,2423,2471,2912,2923	
									R2932	
148	RES	0603001.001	RES		51 (ERJ-3GSYJ510V)	0603	PANASONIC	12	R1036,1325,1434,1435,1446,21	S
									R2320,2430,8003,8004,8016,9097	
149	RES	0603015.001	RES		510 (ERJ-3GSYJ511V)	0603	PANASONIC	6	R1939,2031,2032,2914,8400,8402	S
150	RES	0603029.001	RES		68 (ERJ-3GSYJ680V)	0603	PANASONIC	11	R1312,1313,1382,1412,1413,1482	S
									R2362,2472,2942,2945,2948	
151	RES	0603017.001	RES		680 (ERJ-3GSYJ681V)	0603	PANASONIC	2	R1926,2921	S

ITEM		GLOCOM/N	DESCR.		PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
152	RES	0603101.001	RES		75 (ERJ-3GSYJ750V)	0603	PANASONIC	1	R1511	S
153	RES	0603039.001	RES		750 (ERJ-3GSYJ751V)	0603	PANASONIC	1	R1906	S
154	RES	0603018.001	RES		910 (ERJ-3GSYJ911V)	0603	PANASONIC	12	R1920,1922,1923,1928,1941,1943	S
									R1951,1953,2911,2913,2931,2933	
155	RES	0603082.001	RES		1.15K (ERJ-3EKF1151V)	0603	PANASONIC	2	R1009,1010	S
156	RES	0603042.001	RES		1.5K (ERJ-3GSYJ152V)	0603	PANASONIC	1	R1403	S
157	RES	0603084.001	RES		1.8K (ERJ-3GSYJ182V)	0603	PANASONIC	1	R1908	S
158	RES	0603025.001	RES		100K (ERJ-3GSYJ104V)	0603	PANASONIC	12	R10,1016,1026,1902,31,40,50,60	S
									R70,80,90,9090	
159	RES	0603007.001	RES		10K (ERJ-3GSYJ103V)	0603	PANASONIC	13	R1431,1432,1757,1758,1911,1931	S
									R1933,1938,2110,2916,2925,2927	
									R8041	
160	RES	0603111.001	RES		11.0K (ERA-3YEB113V)	0603	PANASONIC	1	R1302	S
161	RES	0603056.001	RES		15K (ERJ-3GSYJ153V)	0603	PANASONIC	4	R2061,2062,2071,2072	S
162	RES	0603102.001	RES		1K (ERJ-3GSYJ102V)	0603	PANASONIC	8	R1,11,1441,1442,2010,2422,2424,7015	S
163	RES	0603072.001	RES		180K (ERJ-3GSYJ184V)	0603	PANASONIC	2	R2044,2045	S
164	RES	0603085.001	RES		2.05K (ERJ-3EKF2.05KV)	0603	PANASONIC	1	R1035	S
165	RES	0603086.001	RES		2.32K (ERJ-3EKF2.32KV)	0603	PANASONIC	2	R1001,1005	
166	RES	0603087.001	RES		2.7K (ERJ-3GSYJ272V)	0603	PANASONIC	12	R1002,1006,1102,1373,1404,1473	S
									R2063,2065,2073,2075,2341,2461	
167	RES	0603088.001	RES		2.87K (ERJ-3EKF2.87KV)	0603	PANASONIC	2	R1020,1030	S
168	RES	0603021.002	RES		20.0K (ERA-3YEB203V)	0603	PANASONIC	8	R1014,1018,1019,1021,1024,1028	S
									R1029,1031	
169	RES	0603074.001	RES		220K (ERJ-3GSYJ224V)	0603	PANASONIC	2	R2040,2041	S
170	RES	0603022.001	RES		22K (ERJ-3GSYJ223V)	0603	PANASONIC	20	R1392,1937,1972,1974,1976,1977	S
									R2042,2043,2067,2077,2081,2082	
									R2083,2091,2092,2093,2391,2481	
									R2918,8040	
171	RES	0603058.001	RES		27K (ERJ-3GSYJ273V)	0603	PANASONIC	3	R1932,2403,2926	S
172	RES	0603115.001	RES		3.0K (ERJ-3YEB3.0KV)	0603	PANASONIC	1	R1402	S
173	RES	0603047.001	RES		3.9K (RM06J392CT)	0603	CAL-CHIP	1	R1443	S
174	RES	0603059.001	RES		30K (ERJ-3GSYJ303V)	0603	PANASONIC	1	R1303	S
175	RES	0603023.001	RES		33K (ERJ-3GSYJ333V)	0603	PANASONIC	6	R1372,1472,2305,2342,2405,2462	S
176	RES	0603112.001	RES		390K (RM06J394CT)	0603	CAL-CHIP	1	R1910	S
177	RES	0603048.001	RES		4.7K (RM06J472CT)	0603	CAL-CHIP	3	R12,123,124	S
178	RES	0603019.001	RES		5.1K (RM06J512CT)	0603	CAL-CHIP	4	R2064,2066,2074,2076	S
179	RES	0603049.001	RES		5.6K (RM06J562CT)	0603	CAL-CHIP	1	R2303	S
180	RES	0603064.001	RES		51K (ERJ-3GSYJ513V)	0603	PANASONIC	8	R1371,1471,1973,1978,2343,2463	S

ITEM		GLOCOM/N	DESCR.		PART NUMBER	PACKG.	MANUF	QTY.	LOCATION	S/T
									R8001,8002	
181	RES	0603066.001	RES		68K (ERJ-3GSYJ683V)	0603	PANASONIC	2	R1936,2917	S
182	RES	0603089.001	RES		8.25K (ERJ-3EKJ8251V)	0603	PANASONIC	1	R1032	S
183	HDW	BAR005.002	HDW		B-250-12-0.5-0 (Bus Bar Stiffener)		Circuit Components	2		
184	HDW		HDW		Screw, FHD, 100°, .112-40x.44			2	For Item 190	T
185	HDW		HDW		Washer, FLT, #4 Red			2	For Item 190	T
186	HDW		HDW		Nut, .112-40, Self-Lock, Red			2	For Item 190	T
187	HDW		HDW		49-CBSA-1.5x2.75x0.4 (Shield)		LEADER TECH	1	SHELL 3	T
188	HDW		HDW		49-CBSA-1.25x2.5x0.4 (Shield)		LEADER TECH	9	SHELL 1,5,6,61,62,63,64,65,66	T
189					93-3 (Extractor)		EG & BIRTCHE	2		
190					4051759-9 (Bumper)		Arizona Ind. HW	2		