

# **Bluetooth Keyboard for Surface 3**

## **User's Manual**

### **UKB-2030**

Version 1.0 2015/09

ID NO:

## **About This Manual**

This manual is designed to assist you in installing and using the Bluetooth Keyboard. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice.

## **Edition**

1<sup>st</sup> Edition,

## **Copyright**

© Copyright 2015

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

## **Trademarks**

All trademarks and registered trademarks are the property of their respective owners.

## **FEDERAL COMMUNICATIONS COMMISSION STATEMENT**

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio

or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.


# Introduction

Thank you for purchasing the **Hinge Flexible Bluetooth Keyboard**. This User's Manual contains information that will help to operate the device as well as answering questions about certain special keys and buttons. Please keep this manual in a safe place for future reference.

## System Requirements

- Surface 3

## Device pairing

1. Turn on the Bluetooth connection on the Surface 3
2. Turn on the keyboard power and press the “Fn +  (Esc)” button. (Please make sure the blue LED is flashing)
3. The Surface 3 will search automatically. When “Bluetooth Keyboard” shows, choose “Connect”.
4. Enter the pin code that display on the Surface 3 and press “Enter”.
5. Start using the Bluetooth keyboard.






- Note:**
- 1. After 10 minutes non-operation, the keyboard will go to sleep mode. Please press any key to wake up.**
  - 2. The buttons print in blue all requires pressing the “Fn” key with the key to enable its function. (Except the number keys)**

## **Installation Process**




Place the Surface 3 on holder for viewing pleasure:



## Hot key function:

Function Name		Function Description
	Mute	Mute the device's sound volume. Press it again to turn the system volume back on.
	V-	Decrease the device's sound volume. Hold on to decrease volume more quickly.
	V+	Increases the device's sound volume. Hold on to increase volume more quickly.
	Play/Pause	Switch between Play and Pause. Once Pause is pressed, pressing this button again to resume playing.
	Search	Search files.



	Share	Share files
	Device	Connecting external devices
	Setting	To set function changes

**Smart Touchpad supports various multi-finger taps and gestures to perform various functions.**

**For Win 8:**

- Single-finger slides : Mouse cursor manipulation
- Tap: Left button click. Double-tap: double click
- Two-finger tap : Right button click
- Two-finger slides: Horizontal or Vertical Scroll
- Two-finger pinch: Zoom in or Zoom out
- Edge swipe (right): Toggle the Charms.
- Edge swipe(left): Switch to Last App

## **For Win 10:**

- Single-finger slides : Mouse cursor manipulation
- Tap: Left button click. Double-tap: double click
- Two-finger tap : Right button click
- Two-finger slides: Horizontal or Vertical Scroll
- Two-finger pinch: Zoom in or Zoom out

## **Rechargeable Battery:**

- ◆ Please charge the battery before using until the red LED turn off.

### **CAUTION**

- ◆ **RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE .**
- ◆ **DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.**