

SAR Test Setup




Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 2: Front Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 3: Left Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 4: Right Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 5: Top Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 6: Back Side, the distance from EUT to the bottom of the Phantom is 0mm




Picture 7: Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 8: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 9: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 10: Top Edge, the distance from EUT to the bottom of the Phantom is 0mm