

Description of Operation

The Wrist Transmitter (WTR-C) is designed sized and looks like a wristwatch, and is to be worn on the wrist at all times. The WTR-C brings help to your door when you need it most by pressing the button, which is on the top of it. The design ensures triggering the alarm is easily done while cautious handling to prevent false alarm is unnecessary.

- ***Active Button***

- Pressing the Active Button will activate the Main Unit, causing it to dial emergency call or alarm.
- When the Main Unit receives the alarm signal and is being activated, you can stop the activity if desired by pressing this button for more than 8 sec.

- ***The Wrist Transmitter's ID Code***

Every Wrist Transmitter has a unique numeric code called "ID code". The ID code enables the Main Unit to identify the signal is transmitted from the Wrist Transmitter. At the same time, it also prevents interference from outside sources.