

ONB15TA201, ONB15TA202

07/17/15



BLUETOOTH® KEYBOARD
FOR TABLETS AND SMARTPHONES



Works with iOS, Android, or Windows operation system

Model: ONB15TA201, ONB15TA202

PRODUCT GUIDE

NOTE: Regarding battery life:
Continues use: up to 25 hours, **Stand by:** 250 hours.

In the box



Bluetooth® Keyboard

Micro USB Cable


User Manual

Using the wireless bluetooth keyboard

Charging the keyboard

Charge your Bluetooth Keyboard fully before use.

1. Connect the small end of the included Micro USB Cable to the USB charging port on the side of the Keyboard.
2. Connect the large end of the included Micro USB cable to an available USB port on your charging station (or other devices made for USB charging).



AC HOME USB CHARGER


COMPUTER

While charging, the red indicator light is on.

Connect to Micro USB port.

Turning the Keyboard ON/OFF

1. To turn ON, Slide the switch to the ON position and the power indicator will light up.
2. To turn OFF, Slide the switch to the OFF position.




Power Indicator Light

Pair Button

Pairing the Keyboard to a Bluetooth enabled device


1. Make sure the Bluetooth Keyboard is turned ON.
2. Press the [Connect] button once until the Bluetooth indicator is blinking blue. The Bluetooth keyboard is now in a pairing mode.
3. Keep the Keyboard and device (or other Bluetooth device) within 2 feet of each other during the pairing process.
4. Click Settings icon of your device and turn on the Bluetooth function.
5. The device will search for the keyboard automatically.



Blinking

Pair Button

Android connecting settings



Bluetooth

Bluetooth Keyboard HT7.1


Bluetooth pairing request

Tap to pair with Bluetooth Keyboard

Tap on [OK] to accept Return to Enter

Cancel

7. After pairing successfully with the tablet, "Bluetooth Keyboard HT7.1 Connected" is displayed. To disconnect, turn the Keyboard OFF.



PAIRED DEVICES

Bluetooth Keyboard HT7.1

Connected

AVAILABLE DEVICES

A44C11A07F4B

NOTE: When turned ON, the Keyboard will automatically connect to the last tablet (or other Bluetooth device) that it was paired with. To switch to another device, turn OFF the tablet or device and restart the pairing process with the new device.

NOTE: Most Bluetooth enabled devices will connect to the keyboard the on the first attempt. If your device does not connect to the keypad, see "Pairing the Keyboard with a Bluetooth device" and repeat the pairing process. Or, depending on your device, press the "Refresh" or "Search Again" button your device's Bluetooth screen.

IOS (Apple) connecting settings

Step 1:

On your iPad®, tap the  icon from the Home Screen.

Step 2:

Click **General**.




Settings

General

Step 3:

Click **Bluetooth**.



Bluetooth

Bluetooth Keyboard HT7.1

Tap to pair

Accessory

Tap to pair

advanced

Step 4:

Toggle Bluetooth to On.



Bluetooth

Toggle Bluetooth to On

Step 5:

The keyboard will show up under **Devices** on the iPad. Select **Bluetooth Keyboard HT7.1**

Step 6:

A code will appear on the screen. Enter this code on the keyboard and click **Enter**.



Bluetooth

Bluetooth Keyboard HT7.1

Tap to pair

Accessory


Tap to pair

advanced

A message will pop up when pairing is successful. If pairing fails, repeat the steps above.

Windows phone connecting settings

1. On the start screen, swipe left, and tap **Settings**.
2. Switch **Status** to **On**.
3. Make sure the Wireless Keyboard is on.
4. To pair your phone and the Bluetooth Keyboard, tap the **Bluetooth Keyboard HT7.1** in the list.
5. A code will appear on the screen. Enter this code on the keyboard and click **Enter**.



SETTINGS

Bluetooth

Bluetooth Keyboard HT7.1

Tap to pair


Accessory

Tap to pair

advanced

Surface connecting settings

1. On the start screen, swipe left, and tap **Settings**.
2. Tap or click **Change PC Settings**, tap or click **PC and devices**, and then tap or click **Bluetooth**.
3. Switch Status to **On**.
4. Make sure the Bluetooth Keyboard is on.
5. To pair your Surface and the Bluetooth Keyboard, tap the **Bluetooth Keyboard HT7.1** in the list.
6. A code will appear on the screen. Enter this code on the keyboard and click **Enter**.



PC and devices

Manage Bluetooth devices

Bluetooth

Bluetooth Keyboard HT7.1

Ready to pair


Surface Pen

Paired

Using the Function Keys

Activation OS with Keyboard

The keyboard is compatible with iOS, Android and Windows OS. The keyboard will recognize and switch systems automatically after connection, but you need to manually activate each device OS first by pressing the FN key and the operation keys together one time as described below.



Function keys: F1-F12, Ctrl, Alt, Shift, Enter, Backspace, etc.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Bluetooth

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

iPad is a trademark of Apple Inc., registered in the U.S. and other countries.

All trademarks and trade names are those of their respective owners.

* Some function keys may not be available in select operating systems.

Legal information

READ AND KEEP THESE INSTRUCTIONS

FCC Part 15:

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11222

Customer Support:
Phone: 1-877-768-8481 (Toll Free)
Or via the web:
www.southern telecom.com
Click on "Product Support"

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM, INC., ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Discontinued by Wal-Mart Stores, Inc. Bentonville, AR 72716, Printed in China

Limited warranty

In the unlikely event that this product is defective, or does not perform properly, you may within One (1) Year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11222

Customer Support:
Phone: 1-877-768-8481 (Toll Free)
Or via the web:
www.southern telecom.com
Click on "Product Support"

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM, INC., ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Discontinued by Wal-Mart Stores, Inc. Bentonville, AR 72716, Printed in China

-1-

-2-

-3-

-4-

-5-

-6-

-7-

-8-

-9-

-10-

-11-