



1. All the safety and operating instructions should be read before the appliance is operated.
2. All operating and user instructions should be followed.
3. The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, Laundry tub, in a wet basement, or near a swimming pool. Etc. It should not be exposed to dripping or splashing water, and no Objects filled with liquid, such as a vase, should be placed on the appliance.
4. Warning: To reduce the risk of fire of electric shock, do not expose this appliance to rain or moisture.
5. The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; Or placed in a built – in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings .

Speaker	1pc
Operation manual	1pc
USB cable	1pc



- ③ **Standby:**  
Long press to Turn ON and Turn OFF the unite
- Ⓜ **Pairing - Play/Pause:**  
Under Bluetooth mode, long press entering pairing mode.  
Under Bluetooth and MicroSD card mode, short press to pause/play music
- ☎ **Calling:**
  - a. Under Bluetooth mode, short press to answer the call and long press to reject the call.
  - b. Long press to switch between Bluetooth, MicroSD and AUX mode.
- ④ **Volume decrease:**  
Short press to decrease the volume  
under Bluetooth and MicroSD card mode, press entering previous song.
- ⑤ **Volume increase:**  
Short press to increase the volume  
under Bluetooth and MicroSD card mode, press entering next song.

- Turn on the unit, W5 will automatically search the Bluetooth device. If the device paired before, W5 will connect automatically. If can't find paired device, W5 will enter pairing mode automatically.
- Active "Bluetooth" function on your device and search for "Fenda W5".
- Enter "0000" if your device asks for the PIN code.

(Please print the name & address)

(Please print the name & address)

\*\*\*\*\*


Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China  
P.C. : 518108 [Http://www.fenda.com](http://www.fenda.com)

\*\*\*\*\*

Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China  
P.C. : 518108    [Http://www.fenda.com](http://www.fenda.com)

**P.C: 518108**

1. Connect mini USB port of unit to computer or charger's USB port using USB cable included in the package.
2. Charging LED bright after finishing charging
3. Recommend to charge the unit once every month and turn off the unit if not use.




Power Output: 3W  
Frequency Response: 80Hz-20KHz  
Power Input: 5V=500mA  
Separation: ≥40dB  
S/N Ratio: ≥75dB  
Product dimension: W93 x D34 x H81mm

3. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:






- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

4. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



注：此处虚线部分  
需要可扯开的 虚线裁切

展开尺寸	350X120MM
成型尺寸	70X120MM
材质要求	80g书纸
印刷要求	单黑正反印刷
工艺要求	无处理
页码数(页)	折页

 <b>F&amp;D 番达科技</b>		时 间	2016.05.04	订 单 号	
品 牌		公司型号	W5	客户型号	W5
版 本	A0	设计内容	说明书	料 号	
电 子 软 件		结 构 电 声		PLM文档编号	
设 计 者	崔育欢	标 准 化		项 目 经 理 产 品 经 理	
复 核		业 务		核 准	