

80mm

80mm

onn.TM

Indoor Speaker Quick Start Guide

What's in the Box?

Check to make sure you have everything below.

1

2

3

1. Bluetooth Speaker

2. Charging Cable

3. Quick Sart Guide

Get to Know Your indoor speaker

Top

Right

1. LED indicator

2. Power switch

3. Bluetooth

4. Volume down

5. Play/Pause/ Speakerphone

6. Volume up

7. Microphone

8. Reset

9. Aux in

10. Output charging port

11. Input charging port

Power

Long press to power on / off the speaker

ON/OFF

>2s

Bluetooth® Connection

Activate the Bluetooth function on your device and search Bluetooth devices, then select “onn. Indoor SPK LG GRY” to start connecting.

AAAGRY100006902

6 81131 30990 5

Aux Connection

Use a 3.5mm cable (not included) to connect the speaker to another audio source. Press Play on the device and adjust the volume on the unit to obtain the desired volume.

80mm

(not included)

Answer calls

Short press to answer the call
Long press to reject the call

<1s

>3s

Party Sync Mode

Power on one speaker and hold Bluetooth button 3 seconds to enter into pairing mode, this device will be the master. The second device will connect automatically to the master when turned on.

After the two speakers are paired together, use your mobile device to pair with the master speaker utilizing the Bluetooth pairing method.

>3s

TWS

But Wait ... There's More!

The Party Sync Mode also applied to another onn speaker.

Need help?
We're here for you every day
7 a.m. – 9 p.m. CST.
1-888-516-2630
Give us a call!

The Fine Print

USER MANUAL INSERTS FOR FCC ID

1. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

The Fine Print

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

☐

Reorient or relocate the receiving antenna.

☐

Increase the separation between the equipment and receiver.

☐


Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

☐

Consult the dealer or an experienced radio/TV technician for help.

3.The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Rating Lable is located at the bottom of the product.



展开尺寸	480X80MM	F&D 奋达科技		时 间	20191213	订 单 号	GM191138
成型尺寸	80X80MM	品 牌	ONN	公司型号	WT2026	客户型号	AAAGRY100006902
材质要求	120g书纸	版 本	A0	设计内容	说明书	料 号	
印刷要求	两色印刷 两面印刷	电 子 软 件		结 构 电 声	黄永辉	业 务	陈琳云
工艺要求	无处理	设 计 者	张劲松	标 准 化	李洪波	项 目 经 理	谭 玮
页 码 数 (页)	风琴折	备 注	每单更新				

字体：Graphik Regular
字号：不小于8PT